



## QUICK START GUIDE (ENGLISH)

### Welcome!

Thank you for purchasing Renny JR.™, the most advanced *Bluetooth*® Ringer on the market. Renny JR.™ connects automatically to your smartphone with our proprietary Autolinx™ technology, eliminating the need to manually connect when receiving calls or playing music.\* Renny JR.™ has an incredible range to accommodate most homes when placed in a central location such as a kitchen or living room.\*\* However, if you require additional range visit [www.olenstechnology.com](http://www.olenstechnology.com) to purchase an optional external antenna to screw into the gold connector on the back of Renny JR.™.\*\* No other product this size offers the phone management technology and audio quality offered by Renny JR.™. We are confident that Renny JR.™ will become one of your favorite phone accessories!

## Procedures, General Operation

### Turning on the device

1. Using the provided USB Adaptor, plug Renny JR.™ into a powered wall outlet.
2. Switch the power slider on the side of Renny JR.™ to ON.
3. Renny JR.™ is designed to always stay on and plugged in.

### Adjusting Volume

1. Press + and - buttons to adjust volume up and down. An audible beep will be heard when Maximum Volume is reached, although additional volume may be possible using your phone's volume controls.

## Procedures, Phone Operation

### Connecting your Phone the First Time

1. Verify the Renny JR.™ is turned on. The power switch LED will blink.
2. Connect your mobile phone to the device via the *Bluetooth* settings for your phone. See your phone manual or service provider for details. Enter "0000" if asked for a password. Additional *Bluetooth* connection information is also available at [www.olenstechnology.com](http://www.olenstechnology.com).

3. **Note:** The Renny JR.™ can only be connected to 1 phone at a time. However, the Renny JR.™ can be paired to more than 1 phone at a time by repeating Steps 1 and 2 above as long as a previously connected phone is out of range or turned Off. Renny JR.™ will then connect to the first paired phone that comes within range.

### Changing Ringtones (Android™ only, iPhone® uses iPhone ringtone)

1. Press the Ringtone  button until a desired ringtone is found.

### Power Down

1. Switch the power slider on the side of the Renny JR.™ to OFF (The LED should turn off).

## Procedures, Music Operation

Renny JR.™ will stream music from your smartphone or tablet when connected. Please refer to your phone's manual as music player applications vary depending on the make and model of your smartphone or tablet.

## Troubleshooting

### The Renny JR.™ won't turn on.

1. Confirm Renny JR.™ USB Adapter is connected to the device. DO NOT USE ANY OTHER ADAPTER!

### My phone isn't detecting the Renny JR.™.


1. Make sure your device is *Bluetooth* enabled.
2. Verify the device is turned on.
3. Consult phone manual for *Bluetooth* settings.
4. Make sure the phone is within range.\*\*

### Reset Button.

1. Renny JR. is equipped with a Reset Button that erases the memory of all previously paired phones. To activate, Press and Hold with a paperclip for 3 seconds. **Note:** The Reset Button does not erase your phone's *Bluetooth* memory of paired devices, so you must also unpair the Renny JR. on your phone by referring to your phone's manual.

## Specifications

Working Voltage: 5V / Output Power: 3W  
Size: W90\*L90\*H40mm / Weight: 203 Grams  
Speaker Spec.: 52mm 4Ω 3W  
Frequency Response: 80HZ-20KHZ  
Distortion: ≤0.5% SNR: ≥95dB



## Contact Information

If you need help setting up Renny JR.™ or need to troubleshoot, please go to the "support/troubleshooting" tab at [www.olenstechnology.com](http://www.olenstechnology.com) or contact us directly by email or phone (below). Our goal is for you to be 100% satisfied with your purchase, and if you are not for any reason, please let us know. If you purchased from a retailer, please do not contact them. We're here to help! Please contact us directly:

**Address:** Ölens Technology

P.O. Box 386

Pismo Beach, CA 93448

**Phone (USA):** +1(805) 489-3636

**Website:** [www.olenstechnology.com](http://www.olenstechnology.com)

**Email:** [info@olenstechnology.com](mailto:info@olenstechnology.com)

## Warranty

12 months, covers factory defects only. Damage from misuse, impact or incorrect USB Adapter is not covered. No other warranties are covered or implied. See [www.olenstechnology.com](http://www.olenstechnology.com) for additional warranty information.

\*Some cellular phones lose connection after usage, please check the specification of your cellular phone for more details.

\*\* The introduction of objects and/or walls between the Renny JR.™ and the connected phone(s) can significantly reduce the range.

## Certifications



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: [1] This device may not cause harmful interference, and [2] this device must accept any interference received, including interference that may cause undesired operation.

Ölens Technology



## SAFETY INFORMATION

**WARNING!** Please read these safety warnings and cautions to ensure your personal safety and prevent property damage.

### Fire and Electric Shock Hazard

Do not expose Renny JR.™ to liquid, moisture, humidity, or rain. Do not use Renny JR.™ near a bathtub, sink, sauna, pool, or steam room. Exposure of Renny JR.™ to moisture could result in electric shock.

Do not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint, or insert foreign objects in to Renny JR.™. Such actions could result in electric shock.

Clean Renny JR.™ only with a dry cloth.

Do not expose Renny JR.™ to extremely high or low temperatures.

Do not leave Renny JR.™ in direct sunlight for extended periods of time.

Do not leave Renny JR.™ near open flames such as cooking burners, candles, or fireplaces.

Do not block any ventilation openings.

### Adapter Hazard

Do not dispose of Renny JR.™ in a fire. It could explode causing injury or death.

Do not attempt to disassemble the Renny JR.™ adapter or force open the built in battery because this may result in electric shock.

Do not use Renny JR.™ in damp areas or in extremely high or low temperatures because this could result in electric shock.

Do not clean Renny JR.™ when it is plugged in. Always unplug the adapter first before cleaning Renny JR.™.

### Automobile Accident Hazard

Do not leave or store Renny JR.™ or any of its accessories near or over your automobile's air bag because serious injury may result when air bag deploys.

### Fall Hazard

Do not place Renny JR.™ on high surfaces such as shelves. During music playback Renny JR.™ may move which could cause Renny JR.™ to shift and fall off the edge.

### CAUTION!

Do not use abrasive cleaners to clean Renny JR.™ because this could cause scratches and damage.

Do not bring Renny JR.™ in to contact with any sharp objects because this could cause scratches and damage.

Do not insert anything into Renny JR.™ unless otherwise specified in the user instructions. This may damage the internal components.

Do not attempt to repair, modify, or disassemble Renny JR.™ yourself, it does not contain any user-serviceable components.

Use only the manufacturer supplied adapter to charge Renny JR.™. Other adapters may look similar, but using them could result in electric shock and could damage Renny JR.™.

Observe all signs and displays that require an electrical device or RF radio product to be switched off in designated areas.

Turn off Renny JR.™ prior to boarding an aircraft. Do not use Renny JR.™ inside an aircraft unless allowed by the airline.

Dispose of Renny JR.™ in accordance with local regulations.

### FCC Disclaimer

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

### This device complies with Part 15 of the FCC rules.

Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

### Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

### RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

U.S. Patent No.7,945,292. Renny JR. is a trademark of Ölens Technology. Android is a trademark of Google Inc. iPhone is a trademark of Apple Inc., registered in the U.S. and other countries. Bluetooth is a registered trademark of Bluetooth SIG. All other trademarks identified herein are the property of their respective owners.

© 2014 Ölens Technology. All Rights Reserved.