

Mobile phone user documentation

Safety precautions

Using a mobile phone before, please read the following carefully and conscientiously abide by the rules.



All the mobile phone may be susceptible to interference, thus affecting its performance.



In order to ensure the best performance, to avoid damage to the mobile phone, please use the original accessories and batteries, do not use non matching products.



In order to avoid the interference of blasting operation, at the site of the explosion or post "turn off the two-way radio" icon place should close the mobile phone. Pay attention to and comply with all relevant rules or regulations.



When your mobile phone needs to be connected with other equipment, please read the user manual to ensure the safety of equipment.



Please store your backups of important information in the mobile phone or keep a written record, to prevent the loss of important information.



In marked do not use mobile phone near medical equipment and medical establishments, please turn off your mobile phone.



In the gas station and near fuels and chemicals and other dangerous goods place, please turn off the mobile phone, to avoid explosion.



Do not burn the mobile phone battery or the battery as ordinary garbage treatment, to avoid the occurrence of danger to life and cause damage to the environment. Please observe the local government's environmental policy, timely treatment and recovery.



Some small parts (such as a memory card, etc.) should be placed in the reach of children, to prevent children swallowing or other dangers.



Mobile phone communication network for the plane interference, please ensure that the mobile phone in the whole flight process shuts down or flight mode.

Preface.:

Mobile phone users dear, thank you for your purchase of the mobile phone

The use of the mobile phone will bring you a hitherto unknown surprise experience: the mobile phone support dual GSM card and dual standby function, Colorful, let you in memory. Professional MP3 music player, the MP4 image on the full range of multimedia sharing, whole body comfortable
Install

a memory card

Your mobile phone supports T-Flash memory card, insert a memory card, you can browse, copy the file operation on the storage card by mobile phone, mobile phone storage space can be expanded.

Remove the rear cover and battery, according to the direction of the open storage card that Kakage; The memory card with gold contacts side down, card the narrow end first into the card slot until the card slot, and fully consistent, close the card to complete the installation.

The start-up and shutdown

Boot

Press and hold the button hang up about three seconds boot.

Shutdown

Press and hold the button hang up about three seconds off.

Dial telephone

Direct dial

The standby mode, press the keyboard area, enter the area code and telephone number

According to (dial 1) chose to use the card 1 call, or choose to use the card 2 call.

Use the mail list call

Enter mail list, to find the information you need to record.

Call press dial key.

Redial recently dialed telephone number

Entering the main menu, select [call records), select a phone number to dial.

Answer or reject the call

Answer the call

A call, press the answer button

Answer second calls

If the mobile phone a call waiting, when you call second call in mobile phone prompt, you can:

Press the answer key to answer a second call, then before the call set automatically to maintain the status

Press the hang up button to reject second calls to the call.

Rejecting calls

A call, press the hang up button refuse to answer.

In call menu

During a call, select Options > < menu can make the following options operation:

Preserve: keep the current call, can be carried out in second groups.

End to end the current phone call: single line.

Main menu: into the main menu.

Recording: call recording.

Mute: the temporary closure of the microphone during a call. Quiet, you can hear each other's voices, but the other party can not hear your voice. Restoration calls selection (unmute) can restore.

Volume: during a call, you can adjust the speaker volume

Information

The establishment of information: SMS edit Writing

In box: storing the received information.

Draft: a draft information storage.

Outbox: out of the sending information in the outbox.

Video camera

Video camera: can take pictures and videos in the preview screen, press the navigation key switch photographic or video

Music Player

After starting to play music, choose to store music files in mobile phone or T-Flash player, in the settings menu can also customize the shuffle, repeat single player, all repeat and background play.

File management

Edit to memory card folder.

In the file management, press the [options], you can perform the following operations:

Open: open the folder.

The new folder: in the selected folder directory to the new folder.

Rename: to rename the folder.

Delete: delete the selected file or folder.

Scene mode

Standard mode, silent mode, the meeting mode, outdoor mode, you can set the switch machine ringing, ringing, ringing tone, manner, information adjust the ring volume etc..

Set up

Mode: you can choose to use a single SIM or dual SIM card.

Flash light: Click into the flashlight on or long press the OK key to open

Mobile phone settings: enter the menu can be set the time and date, machine, the default language, input method, phonetic, standby menu.

Network settings: choose network

Security settings: for mobile phone lock, boot need to enter a password to boot (the default password: 1122)

Notification settings: open the notification service, receive information popup remind.

Restore factory settings: return to factory settings. (Code: 1122)

Call center

Call records: to view have been broadcast telephone, received calls, the missed call records.

Call settings: call waiting, call forwarding, call restriction requires network support; in the advanced

settings can also be opened automatically replay, IP dialing, call time reminder, answer mode, you can set according to their own needs.

The telephone book

Save contacts to the phone book. The main interface can choose the phone book contact call, send SMS , IP dialing, edit, copy, delete, mark, group setting where you can add group, the phone can view the storage state thin set menu, copy, move, delete all contacts.

Entertainment

The machine has a single puzzle game.

Multi-media

Mobile TV: Enter the mobile TV, you can search a clear platform for viewing

Video camera: can take pictures and videos in the preview screen, press the navigation key switch photographic or video.

Album: to view photos and downloaded to the mobile phone in the picture.

Video: video player supports AVI, 3gp, MP4 format video playback.

Mobile phone movie: the video file to download to the T-Flash card under the "Movie" folder, video format support avi, 3gp, mp4.

Music player: can start playing music, can choose the stored in the mobile phone or T-Flash music file playback, in the settings menu can also custom random play, single repeat, all repeat and background play.

Recording: can start recording.

FM: headsets, headphones inserted can listen to FM radio.

Extras

Calculator: the calculator can be used to calculate.

Bluetooth: Bluetooth function to other Bluetooth file transfer / receive documents, and can link the Bluetooth headset, Bluetooth headset and listen to music; data account can select data transfer mode.

Organizer

Calendar: view of calendar the options menu to add a reminder

Alarm: the mobile phone provides 5 alarm clock, can be opened simultaneously. Each alarm can be set a single reminder, every day to remind, custom remind 3 modes. You can set the alarm time, repetition and bell type.

Mobile phone maintenance

Mobile phone is the electronic products of high precision, please careful maintenance. The following suggestions can help you maintain the mobile phone, mobile phone service life extension:

Mobile phone and accessories should be placed in the reach of children.

Keep mobile phone drying. Rain, humidity or moisture corrosion circuit board. If the mobile phone accidentally inlet, batteries should be removed promptly, and immediately sent to a local Xiaxin authorized service center for processing.

Do not use mobile phone placed in the dusty place, otherwise it will affect the normal use of the mobile phone.

Liquid crystal display is more easily damaged components in the mobile phone, mobile phone should avoid to fall to the ground or shaken; the prohibition of the use of sharp objects touch screen.

Do not put the mobile phone in the high temperature. High temperature will shorten the life of electronic devices, destruction of the battery, the mobile phone plastic shell deformation or melting.

Do not put the mobile phone in the low temperature. Otherwise, when the mobile phone temperature to normal temperature, internal have moisture generation, will damage the mobile phone electronic circuit board.

Do not put the mobile phone in the low temperature. Otherwise, when the mobile phone temperature to normal temperature, internal have moisture generation, will damage the mobile phone electronic circuit board.

Do not throw, percussion or violent shaking the mobile phone, mobile phone so as not to damage the internal circuit boards and fine structure.

Please do not use chemical agents, cleaning solvents or strong detergents to clean the mobile phone application, dip soft cloth gently scrub with soap and water.

Do not use their mobile phone to prevent pigment, detachable parts stuck and influence the normal operation.

Use a soft cloth to clean the lens cleaner. Such as: the camera lens.

Battery charging matters needing attention

The mobile phone use lithium-ion battery to provide the energy, environment, mobile phone set can affect the mobile phone standby and talk time.

In order to make the new battery in best performance, please complete two to three times the battery charge discharge cycle. The new cell initial several charge please continuously charging for 10 hours.

Do not process mobile phone charging with wet hand contact mobile phone battery or charger to avoid danger.

Mobile phone charging, please try not to use the mobile phone.

When the battery is fully charged, the battery icon rolled to a stop, the mobile phone can be removed from the adapter interface charger.

Safety information

The use of the environment

In order to ensure that your rational use of mobile phone, to avoid the impact of you and the environment, please remember to use the mobile phone in any place should comply with the relevant rules and regulations.

In any possible explosion places such as gas station, fuel storage, chemical plant or explosion operation place please turn off your mobile phone, and comply with all safety signs there and the. The relevant provisions of the violation may lead to explosion, cause personal casualty.

Used in the mobile phone may cause interference to aircraft flight operations, risk. Therefore, be sure to turn off your mobile phone before boarding please, and to ensure that the mobile phone is in the off state in the whole flight process.

When driving a car, please send mobile phone placed in special support, do not put in the seat, or in the collision, the brakes may fall. Do not use mobile phone in driving process, to ensure the safety of driving, avoid traffic accidents. If you must use a mobile phone, please make the first parked the car to use mobile phone.

Please put away from high temperature environment of mobile phone, mobile phone battery temperature increases due to avoid explosion.

Medical equipment

In the specified requirements of electronic medical equipment shutdown (such as pacemakers, hearing aids and other medical equipment) near please turn off your mobile phone. Most of the medical equipment with RF signal shielding mobile phone production function, but also some electronic devices do not have this function. In case of doubt or uncertainty of medical equipment is shielded RF signal, please consult a physician or medical equipment manufacturers.

Other safety information

Without the use of mobile phone, we recommend that you close mobile phone, and remove the battery, in order to save energy, eliminate the mobile phone radiation.

In the use of mobile phone, do not turn up the volume is too large, to avoid damage to the hearing.

Non professionals, not to open the mobile phone terminal and battery.

Suggest that you try not to use with magnet buckle leather, in order to avoid a magnet will switch to mobile phone signals caused by disturbance and hard iron could crush the LCD screen; plastic mobile phone sets will cause the steam volatile poor internal components, mobile phone shell and can lead to corrosion, oxidation fade.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment.

Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC

Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment

generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause

harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the

equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: TANK T191 (FCC ID: **2AB9NGENIOTANKRDA**) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 0.758W/kg and when properly worn on the body is 0.849W/kg. This device was tested

for typical body-worn operations with the back of the handset kept 5 mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.5cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly.

The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of **5 mm** must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.