

# M-Show BL-610

## BLUETOOTH SPEAKER STAND SERIES



### User Guide

3

#### Specifications

- 01 Protocol: Bluetooth 3.0
- 02 Working Distance: 5–10 meters
- 03 Audio System: 2.0 channel, Stereo
- 04 Rating Power: 3W\*2
- 05 Speaker Unit: 36mm, 4Ohm
- 06 Frequency Response: 150Hz–20KHz
- 07 S/N Ratio: 80dB
- 08 Working Time: 5 hours
- 09 Power Supply: 5V 500mA
- 10 Charging Time: 3 hours
- 11 Li-ion Battery Capacity: 1050mAh
- 12 LED Power: 0.5W

#### Packing List



M-Show X1

+



USB Cable X1



Warranty Card X1

+



User Guide X1

### M-Show

4

#### Product Display



Bluetooth Power ON/OFF




RESET




USB Charging Port



Lamp Power ON/OFF



Charging LED indicator



Bluetooth LED indicator

### M-Show

5

#### Stand function

- 1: M-Show is compatible with most 7–11 inch tablets in the market.
- 2: Support both portrait and landscape positions.
- 3: Adjust the view angles as you like.



#### Lamp function



- 1: Adjust the lamp for suitable view angles.
- 2: Touch "Q" to operate Power ON/OFF.
- 3: If the lamp system does not work, long press "RESET" button to restore it to the original factory setting.

**Remark:**  
Lamp touch switch is built in sensitive unit; please do not place this product near strong magnetic conditions.

### M-Show

6

#### Bluetooth speaker function

- 1: Turn on power switch, M-Show will issue a power ON tone.
- 2: Two blue indicators flash alternately; the M-Show will go searching for Bluetooth device.
- 3: Go to Bluetooth setting of your device, Search and pair "M-Show" to connect.
- 4: When M-Show issues a connection tone, two blue indicators flash slowly simultaneously, It means the connection has been finished.
- 5: Open the music software in your device. M-Show will bring you to fantastic music tour.

Take mobile phone as an example:



**Remark:** If your Bluetooth device succeed in connecting with M-Show, M-Show will automatically search and pair the device automatically next time in 10 seconds when power on (Two blue indicators flash simultaneously). If it fails to connect, it will turn to searching mode (Two blue indicators flash alternately), you need connect it manually.

- 1: When the battery is low, M-Show will not go smoothly on music playback, please charge.
- 2: Plug the Micro USB cable into M-Show's USB port.
- 3: Connect the USB type A to Computer's USB port or a standard 5V 0.5–1A charging port.
- 4: Red Charging LED indicator on when charging; Green indicator on when fully charged.

**Caution:** Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- 1: Please charge at least once a month if M-Show is not used for a long time.
- 2: Please charge with certified power adaptor.