

尺寸：105x148mm

材质：100g书纸

工艺：双面四色印刷 折页


User Manual

Wireless Keyboard

H111


system support: win11/win10/win8/win7/mac/os/Android/windows xp...

How to set up



- Step 1:** Please put the USB receiver into your computer.
- Step 2:** then turn on the keyboard.
- Note:** The keyboard will automatically connect to the computer, no driver needed.

What to do if the keyboard loses connection with USB?




Pairing method: Long - press the **ESC + = keys** for three seconds until the red light flashes. Then, immediately plug in the receiver.

Shortcut keys

FN Key Function Key	WIN FN+Q	MAC FN+W
	Reduce the Screen Brightness	Reduce the Screen Brightness
	Increase the Screen Brightness	Increase the Screen Brightness
	Window Switching	Window Switching
	Voice Assistant	Siri
	Language Switch	Language Switch
	Sleep	✕
	Copy	Copy
	Pause	Pause
	Copy	Copy
	Email	Email
	Music	✕
	Search Function	Search Function

FN Key Function Key	WIN FN+Q	MAC FN+W
	Screenshot	Screenshot
	Emoji	Emoji
	Lock Screen	Lock Screen
	Previous Song	Previous Song
	Play/Pause	Play/Pause
	Next Song	Next Song
	Mute	Mute
	Vloume-	Vloume-
	Vloume+	Vloume+
	Calculator	✕

Keyboard lighting function



- Num Lock:** The Num Lock indicator will turn red when Num Lock is activated.
- Caps Lock:** The caps Lock indicator will turn red when caps Lock is activated.
- Win:** Fn+Win, Switch to the function of Windows system.
- Mac:** Fn+Mac, Switch to the function of Mac system.and the red light stays on.
- Charging light:** The red light remains on constantly when charging.

Keyboard specifications.

Lenght:	428.77mm
Width:	229.3mm
Height:	33.75mm
Weight:	983g
Button Switch Life:	10 million times
Voltage:	3.7V
Battery Capacity:	4000mAh

FAQ

- Q1: How to fix keyboard delay or sticking?
- A1:
- Check for 2.4GHz devices (e.g., router) nearby.
 - Ensure the keyboard is fully charged.
 - Remove any full-metal casing blocking the signal.
- Q2: What to do if keyboard won't charge?
- A2:
- Check charging port connection; replace the cable.
 - Try a different USB port. Contact us if issue persists.
- Q3: Backlight not working?
- A3:
- Charge for 30 mins, then re-insert USB receiver.
 - Restart keyboard.
- Q4: Where's the USB receiver?
- A4:
- It's under the keyboard.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.