NOGO B7500 user manual

The Chapter I: cautions

- Keep the speaker away from flinty environment: Damp, dusty, reeky and so on.
- Keep the speaker away from water and other liquid. If it occurs, please use a soft cloth to dry it.
- Don't use water or chemical liquid to clean it, please use a soft cloth to clean the surface of the speakers.
- Keep this product away from high temperature, not allowed roasting, baking or drying.
- Be sure the voltage for power ≤3.5V
- Keep this product away from hit of large external force.
- Keep the speaker away from strong magnetic.

Don't open and repair the speaker by yourself.

Warnings:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

FCC RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

- Looks small, sounds big. Blast music, movies, games and more
- Bluetooth 4.0, easy to pair 2 devices at same time
- Dump energy shown by one key
- Up to 8 hours music continuously
- Marvelous soft cover, durable & shockproof
- Good quality sound: supper bass, loud sound, hi-fi music
- Hand free: when call coming, press "Pause/Play" to answer or hang up the phone
- Manage power intelligently
 - --It will enter into energy-saving mode in 5 minutes if it doesn't carry out any task
- --Charging indicator: indicator is red when recharging; indicator is off when battery full charged
 - --When low power, it will give beep tone
- Power bank: if you bought the power bank edition, you can recharge your mobile phone through this speaker

The Chapter III: Package Including

Speaker: 1 pcUSB cable: 1 pcAUX cable: 1 pcManual: 1 pc

* Remark: if you recharge for speaker on wall, the adaptor should be 5V, 1A

The Chapter IV: Product Structure

1. power switch: ON/OFF

2、

Micro Mini USB Slot

Dump energy indicator

AUX slot

Dump energy button

TF card slot

3. Function keys

Prev/ Fast reverse

Next/Fast forward

Mode/Play/Pause/Answer/Hang up

Volume -

Volume +

The Chapter V: Bluetooth Function

Normal Bluetooth connecting

- Turn on the speaker; search the Bluetooth device "NOGO B7500", match and connecting.
- Password (when needed):0000

Bluetooth playing

- When Bluetooth connected, you can play the music which is in your Bluetooth device.
- When playing music, you can control the music through the speaker.

Button function

Pause/Play; Answer/Hang up; If you press it for 2 seconds, it will change the mode among Bluetooth/AUX



Preview song



Next song



Volume -



Volume +

Bluetooth answer the phone call

- During playing music with your mobile phone, when a call coming, speaker will stop to phone call

• Button function



- Touch for answer the phone call, press for 2 seconds to refuse the phone call
- During talking, press for 2 seconds to save the talking and touch again it will continue the talking
 - During talking, touch it to end the talking
 - When talking end, the speaker will back to the former working task



When talking on the phone,invalid



When talking on the phone,invalid



When talking on the phone, decrease the volume



When talking on the phone, increase the volume

The Chapter VI: AUX playing

Connect speaker with smart phone/PC though AUX cable, you can play music directly

Operation control

During playing, touch to pause/play; press for 2 seconds to change mode among Bluetooth/AUX

KKI Under AUX mode,invalid

During playing, decrease volume

During playing,increase volume

The Chapter VII: Recharge

Recharge

- Dump energy indicator: press dump energy button, the indicator will show the situation.

White: 60-100% energy Blue: 10-60% energy Red: less than 10% energy

-Any mode, when connect speaker with PC via USB cable to recharge -If recharge on the wall, please use good quality adaptor: DC5V/1000mA

-Indicator: recharging—redFull recharged—off

Remark 1: please recharge for 10 hours the first 3 time, the other time, according to the indicator

Remark 2: Power bank edition: if the edition you bought has power bank function, you can recharge your mobile phone through this speaker.

Chapter IX: Specification

Category	Item	Description
Bluetooth	Standard	Bluetooth 4.0
	Frequency	2.4-2.48 GHz
	Connection	By hand
	Range	30m
	Profile	HS/HF、A2DP、AVRCP、OPP
Audio	Speaker unit	40mm
	Rated Power	2.5W+2.5W
	Response frequency	100Hz~20KHz
	S/N	S/N≥85 dB
	RATED IMP	4 OHM
	THD	THD≤10%

Power	Туре	Built-in Lion battery 1800mAh
	Rated Power	3.7V
	Voltage	4.2V
Interface	AUX input	3.5mm AUX
	DC-IN input	Mini USB
Spec	Gift box Size	180mm*105mm*70mm
	Speaker Size	164*50*73mm
	Speaker Weight	446grams
	Design patent	201330170836.2