



**1** Short Press:previous song  
Long press:Volume down

**2** ON/OFF  
**2** Long press button  
for 3 seconds

**3** Short Press :Next song  
Long press:Volume up

**4** Answer/Play/Pause

**5** DC Charging Port  
Use a USB cable(included)to charge device by connecting to a computer or a USB wall charge.

**6** MIC

**7** Hook

**8** Speaker

# BLUETOOTH HAND-FREE SPEAKER

## Operation Manual

### Pairing

1. Make sure your speaker is charged.
2. Long press the on/off button for 3 seconds.
3. When your speaker is turned on, the Led light will turn blue. This will indicate that the speaker is now in pairing mode.
4. Turn on your mobile device and ensure Bluetooth is enabled. Search for nearby devices from your phone or tablet.
5. Find BLUETOOTH SPEAKER and connect to your device.
6. Once Paired, you can control audio from your speaker or device directly.

### Troubleshooting

If your speaker is not Pairing or playing:

- Ensure it is correctly paired to your device.
- Ensure your speaker is charged
- Ensure bluetooth is enabled on your device.

Charge voltage:5V	Loudspeaker:40mm 4Ω2W
Net Weight:55G	Size:112*97*43mm
Batteries:220 MAH	Product material:ABS
Charging time:1 Hour	Work time:1 Hour

## **FCC INFORMATION**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by tuning the equipment off and on, the user is encouraged to try correct the interference by one or more of the receiving measures:

Reorient or replace relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

## **FCC WARNING:**

This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless user could lose the authority to operate this equipment if an unauthorized change or modification is made.

## **RF warning statement:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.