

### Compliance Information

**FCC Information**  
This device complies with Part 15 of the FCC Rules.

**Caution:** Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This product complies with the requirements for Part 18 of the FCC Rules. Although this product complies with FCC, it may interfere with other devices. If this product is found to interfere with another device, separate the other device and this product.

**Radiation Exposure Information**  
This device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

**WARNING Li-ion Battery Inside**  
This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).

**Rating Label Definitions**

- Direct current symbol.
-  This symbol represents FCC Declaration of Conformity and compliance.
-  This symbol signifies and declares that this equipment complies with battery charging which complies with California CEC and energy efficiency.
-  This symbol signifies that the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.
-  This symbol signifies that this is a wireless device powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. used under license.

### Warranty Information

**1-Year Limited Warranty**  
Territory: United States/Canada  
LIMITED WARRANTY TO ORIGINAL CONSUMER  
This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:  
To obtain warranty service:  
• Visit our customer support portal: [www.customersupport123.com](http://www.customersupport123.com) and select "Support".  
• Select the brand, fill out the corresponding form (exchanges require dated proof of purchase from an authorized retailer) then submit your request.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier. Warranty service not provided. This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

### Bluetooth

# HELLO KITTY®

Wireless Boombox Speaker



**User Manual**  
HKSPK2PK-F21

### Before You Begin...

**Caution**  
To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer- approved batteries, chargers, accessories, and supplies.

- **THIS DEVICE IS NOT A TOY** – do NOT allow children or pets to use or play with this device.
- Do not disassemble, modify, or repair the device.
- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- Do not submerge in water.
- Low power may cause poor Bluetooth connection or sound distortion.
- Do not overcharge battery.
- If using with a USB adapter, make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.
- The headphones contain built-in batteries and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

**Questions and Customer Support**  
For questions, troubleshooting, or any other assistance, please visit our customer support portal at [www.customersupport123.com](http://www.customersupport123.com), and click "Support".


**Technical Specifications**

- Bluetooth: V5.0
- Bluetooth Range: 33 ft
- Battery Power: 500 mAh
- Driver Size: 3 in
- Driver Power: 5 W
- Playtime: 8 hours (varies depending on settings and usage)
- Charge Time: 3 hours
- FM Radio

**In the Box**

- Wireless Boombox Speaker (x1)
- 2-in-1 Charging/AUX Cable (x1)
- User Manual (x1)

### Location of Controls



### Getting Started

**Charging the Speaker**  
Insert the micro-USB connector of the included 2-in-1 charging/AUX cable into the charging/AUX port on the side of the speaker. Insert the large connector into a USB power source, such as a computer, or into a 5V/1A USB adapter (*not included*), and plug into a wall outlet. The LED indicator will turn **RED** while charging, and will turn **OFF** when fully charged.

**Note:** the speaker will sound a tone when it is low on power, indicating that it needs to be recharged.

**Speaker Controls**

- Move the [Power] switch to power the speaker **ON/OFF**.
- Press the **center** of the Playback Dial to **SCAN RADIO STATIONS (FM)**.
- **Press & hold** the Playback Dial to the **right** to **INCREASE** volume.
- **Press & hold** the Playback Dial to the **left** to **DECREASE** volume.
- **Press & hold** the **center** of the Playback Dial to **SWITCH INPUT MODES**.

**Note:**

- A microSD card or USB device (*not included*) must be inserted to switch to those modes.
- In **AUX Mode** and **Bluetooth Pairing Mode**, volume can also be controlled with your connected device.

**Bluetooth Pairing**

1. Power the speaker **ON**. A tone will sound, and the speaker will enter **Bluetooth Pairing Mode**. The LED indicator will flash **BLUE**.
2. Set your Bluetooth-enabled mobile device to search for Bluetooth devices. When it appears, select "HKSPK2PK" from the list of found devices.
3. After successfully pairing, a tone will sound, and the LED indicator will turn **solid BLUE**. You are now able to play music on the speaker.

**Note:**

- While playing music, the LED indicator will pulse **BLUE**.
- The speaker will automatically pair to previously-connected devices that are within range.
- The speaker will automatically power **OFF** after **10 minutes** if not paired with a device.
- Do NOT have a TF card, USB device and/or AUX cable installed at the same time, as this may cause undesired malfunctions of the speaker.

### Adjusting Playback

With the exception of **AUX Mode**, playback can be controlled with the Playback Dial:

- Press the **center** to **PAUSE/RESUME** audio.
- Press to the **right** to skip to the **NEXT TRACK/STATION**.
- Press to the **left** to skip to the **PREVIOUS TRACK/STATION**.

**Aux Mode**

1. Insert the micro-USB connector of the included 2-in-1 charging/AUX cable into the charging/AUX port on the side of the speaker.
2. Insert the 3.5mm AUX jack end into the 3.5mm AUX output port on your device.
3. Switch input modes until you reach **AUX Mode**.

**Note:** while in **AUX Mode**, all playback is controlled with your connected device.

**FM Mode**

1. Insert the micro-USB connector into the micro-USB charging port, and place the other end in a location where it has an unblocked line of sight to the sky (this will allow it to receive stronger radio frequencies).
2. Switch input modes until you reach **FM Mode**.
3. While in **FM Mode**, all playback is controlled with the speaker:
  - Press the **center** of the Playback Dial to **SCAN RADIO STATIONS**. If not manually stopped, the speaker will scan through and save all nearby radio stations with good reception.
  - Press the Playback Dial to **left/right** to **SKIP THROUGH SAVED STATIONS**.

**microSD Card and USB Device Modes**  
Inserting a microSD card or USB device:

- microSD card: insert it into the microSD card slot on the side of the speaker with the metal contacts facing down, and press until it clicks.
- USB device: insert the USB device (e.g. USB flash drive containing audio files) into the USB device port on the side of the speaker.

To play the audio files on a microSD card or USB device, change input modes until you enter **microSD Card Mode** or **USB Device Mode**. The speaker will automatically begin playing music from the inserted device.

While in **microSD Card Mode** or **USB Device Mode**, all playback will be controlled with the speaker:

- Press the **center** of the Playback Dial to **PLAY/PAUSE** playback.
- Press the Playback Dial to the **left/right** to **SKIP TRACKS**.