
VODKA CRUSER

GO WITH THE FLAVOUR

SOUND CUBE OF SPEAKERS



CAUTION

- . Excessive use of the product may cause hearing damage
- . When using the product children should be supervised by an adult
- . This product is for indoor use only
- . The product should not be exposed to water or other liquids because of the danger of electric shock.
- . Do not attempt to remove the cover or other components. Danger of electric shock
- . Should be placed on an even floor. Sound may vary depending on floor covering
- . Use only the accessories provided (cables and adapter)
- . Max load: 150 kg.
- . Store in a dry place and keep out of direct sunlight and away from heat sources
- May be cleaned with a damp cloth. Do not use cleaning agents
 Remember: When cleaning, turn off the speaker and detach the electrical supply to avoid the risk of electric shock

SOUND SPECIFICATIONS

Output: RMS 5Wx2 + 10W (THD = 10%)

Amplifier:

Subwoofer: > 50dB Satellite: > 60dB


Frequency: 60Hz ~ 15kHz

Distortion:

Subwoofer: <4% (F = 100Hz) Satellite: <1% (F = 1kHz)

Input:

AC 10V/1.2A




CONTROL PANEL

A1 : Audio output jack plug A2 : Audio input jack plug

A3 : Volume A4 : Bass control

A5: 10V AC power input jack plug

A6: On / O



ACCESSORIES


B1:1 pc. 2m RCA stereo cable (male / male connectors)

B2: 1 pc. 20cm RCA stereo 3.5mm cable (male / female connectors)

B3: Output, 10V AC 1200 mA 12W adapter


PLEASE NOTE:

Accessories are stored inside the hidden compartment under the Sound Cube



CONNECT TO THE SOUND CUBE WITH BLUETOOTH:


- 1. Switch on the Sound Cube, you will hear the prompt "Power On, Pairing"
- 2. Turn on the Bluetooth connection on your music device
- 3. Your music device should automatically discover the Sound Cube called "VODKA CRUISER"
- 4. Click on "VODKA CRUISER" to start pairing with the Sound Cube
- 5. Once they are paired you will hear a prompt from the Sound Cube "Pairing completed" and a special tone



CRUISER

SOUND CUBE CONNECTION GUIDE


OMGRAM1 XBOX™, XBOX 360™, PLAYSTATION 3™ & WII





CAGRAM 2 HOME THEATER & SATELLITE

PORTABLE DEVICES

MP3 / CD / DVD / PSP / NDS / IPHONE / IPAD / IPOD







FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Modifications to this product will void the user's authority to operate this equipment.