


## Remote buttons:



Learning remote control(2pcs can be learn at one time),the steps as follow:

1. Under disarm status, open car door and step on foot brake, turn ACC from OFF to ON for 3 times, finally stop at ON position. LED indicator light uninterruptedly which indicating the system has enter into learning status. Or open car door and step on foot brake, turn on the ACC, press emergency button for 3 times, the system will enter into learning status.
2. Press any button within 10 seconds, siren chirp once indicating the first button has been learned successfully.
3. Repeat step 2 to learn the 2<sup>nd</sup> remote(siren chirp twice indicating the 2<sup>nd</sup> remote has been learned successfully); After the 2<sup>nd</sup> remote be learned successfully, the siren will chirp twice indicating the system is going to exit the state of learning mode.
4. During learning process, turn the car key to OFF position, or no action to remote control within 10 seconds, the system will exit the state of learning mode automatically. At this moment the siren will chirp twice too.

When disarm, open the door, turn ACC to ON .

Function model	Setting/ way to change	Siren sound 1 time	Siren sound 2 items
1、Low temperature detection	Press  +  2 seconds	able	※disable
2、timer engine start	press  +  2 seconds	Able	※disable
3、door open alert	Press  2 seconds	※able	disable
4、door open delay, doom light delay.	按  +  键 2 秒	※5seconds	30seconds

with “※” marks are the factory settings

## **FCC ID: 2ABXS-VT368**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.