

## WIRELESS SELF CAMERA MONOPOD

Model: MA-2300



### INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY  
AND RETAIN FOR FUTURE USE

#### GETTING STARTED

- Remove the Bluetooth Selfie Stick with Built-in Shutter Button and other accessories from the box.
- Remove any packaging from the product.
- Please read all instructions and retain all packaging until you have checked and counted all of the parts.

#### PACKAGE CONTENTS

- Bluetooth Selfie Stick with Built-in Shutter Button
- Phone mount
- USB charging cable
- Instruction manual

#### FEATURES

- Mounts most mobile phones & cameras
- Ideal for taking great quality selfies & group pictures
- Capture photos or video above the crowds or in hard to reach places
- Pairs with your iOS and Android devices, once paired just press Shutter button to take photos
- Non-slip soft rubber handle
- Made with high quality stainless steel and plastic material
- Adjustable ball head and thumb screw locks for multiple angle shooting
- Extends up to 41 inches

#### DESCRIPTION OF PARTS



#### OPERATING INSTRUCTIONS

##### CHARGING THE SELFIE STICK

- a. Please use the USB Recharging Cable that is included in the box. Connect one end of the cable to the Micro USB Charging Port as shown in the figure. The other end should be connected to your computer USB Port or other suitable USB source.
- b. While charging the Selfie Stick, red LED light turns on. Once it is fully charged, red LED light turns off.
- c. Note: Before using the product for the first time, please charge the Selfie Stick for around an hour or until the red LED light turns off.

##### INSTALLING THE PHONE ONTO THE PHONE MOUNT

- a. Place the phone mount onto the Selfie Stick and turn clockwise, until it mounts securely.
- b. Place your phone onto the phone mount and secure it tight.

##### PAIRING

- a. Slide the On/Off switch at the bottom of the Selfie Stick, to On position.
- b. The blue LED indicator will begin to flash rapidly. This enables the Bluetooth function.
- c. Switch on Bluetooth function in your phone setting and search for available devices.
- d. Select "SL SELFIESTICK" from the list of available devices, to pair your phone with the Selfie Stick.
- e. After you have successfully paired your phone to the Selfie Stick, you are ready to take photos by pressing the Shutter button on the Selfie Stick.

Note: For iOS 6.0 or above and Android devices OS 4.2 or above, you DO NOT need any external App to use the Selfie Stick. It would take photos on the click of the Shutter button, once paired with Bluetooth.

##### SELECT APPS

While, you DO NOT need any external App to take photos through your Phone's built-in Camera using the Selfie Stick, you can download and install the "Camera360" App (from Google Play) if the built-in camera doesn't support the Selfie Stick.

##### TECHNICAL SPECIFICATION

Extendable length	Up to 41 inches
Retracted length	8.7 inches
Dimension	12.5 x 4.5 x 1.0 inches
Weight	4.50z
Mobile device's size	Up to 3 inches in width

#### FCC Instructions

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### LIMITED WARRANTY

This manufacturer's product warranty extends to the original consumer purchaser of the product. Neither the retailer nor any other company involved in the sale or promotion of this product is a co-warrantor of this manufacturer warranty.

**WARRANTY DURATION:** All materials and workmanship are warranted to the original consumer purchaser for a period of ninety (90) days from the original purchase date.

**WARRANTY COVERAGE:** This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty doesn't cover the following which may be supplied with this product, including but not limited to; LCD Screens, glass parts, lenses, bulbs etc. This warranty is effective only if the product is purchased and operated in USA and Canada,

and does not extend to any units which have been used in violation of written instructions furnished by manufacturer or to units which have been altered or modified or, to damaged products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

**WARRANTY DISCLAIMERS:** This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for manufacturer any other liability in connection with the sale of our products. There shall be no claims for defects or failure under any theory of tort, contractor commercial law including but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract. Under no circumstances will Manufacturer's / Distributor's maximum liability exceed the retail value of the product.

**WARRANTY PERFORMANCE:** During the above 90 day warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at manufacturer's option). The repaired or replacement product will be in warranty for the balance of the 90 day warranty period and an additional one-month period. No charge will be applicable for such repair or replacement.

**SERVICE AND REPAIR:** If service is required for this product, you should first contact Midwest Trading Group Customer Service at [info@mtradinggroup.com](mailto:info@mtradinggroup.com) or by calling 1 (866) 815-4714, Monday to Friday 10am to 6pm EST.

**NOTE:** Manufacturer cannot assume responsibility for loss or damage during incoming shipment. As a precautionary measure, carefully package the product for shipment, and insure it with the carrier. Be sure to enclose the following details with the product: your full name, return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.