





品牌

2021.05.26
V1.0 首次创建

<p>Questions? If you have questions or need help at any time during installation:</p> <p> Search our knowledge base articles by visiting us online: www.GoKinetic.com</p> <p> Call our Support Team: 800-347-1991</p>	<p>Camera Placement</p> <p>1. The camera has a 125 ft. range and should be installed within 125 ft. of your WiFi router or WiFi extender.</p> <p>2. The camera swivels on its magnetic base to your preferred viewing angle. The live view can be rotated 180 degrees, allowing for ceiling mounting.</p> 	<p>Camera Placement</p> <p>3. The camera has a 110 degree field of view. To prevent false motion alerts, it should not point towards windows.</p> 	<p>Light Explanation</p> <p>Yellow (solid) - Power on, initializing</p> <p>Yellow (flashing) - Ready to connect</p> <p>Yellow & Blue (flashing) - Connecting to application</p> <p>Blue (flashing) - Finishing setup</p> <p>Blue (solid) - Setup complete, camera connected successfully</p>	<p>FCC WARNING</p> <p>Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help.</p> <p>FCC RADIATION EXPOSURE STATEMENT</p> <p>This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.</p>	 <p>HD CAMERA INSTALL GUIDE</p>
--	---	---	---	---	--

<p>Package Contents</p> <p>HD Camera x 1 Power Adapter x 1 USB Cord x 1 Adhesive x 1 Magnet Plate x 1 Install Guide x 1</p> 	<p>Kinetic Secure Home App</p> <p>1. Access or download your Go Kinetic app in the Apple App Store or Google Play Store. Scan this QR code to get started:</p> 	<p>Kinetic Secure Home App</p> <p>2. Login to your Go Kinetic app if you are an existing customer; create your password if you are a new customer.</p> <p>3. Locate Kinetic Secure Home under the services tab.</p> <p>4. You can also download the Kinetic Secure Home mobile app for iOS or Android directly from the Apple App Store or Google Play Store.</p>	<p>Setup Instructions</p> <p>1. Insert the USB into the camera power port and wait 30 seconds for camera to initialize. The indicator light will blink.</p> 	<p>Setup Instructions</p> <p>2. Press and hold the RESET button. The camera will sound the voice prompt "Ready to Setup."</p> 	<p>Setup Instructions</p> <p>3. In the Kinetic Secure Home app, tap "Add New Device," then select HD Camera.</p>	<p>Setup Instructions</p> <p>4. Make sure your phone is connected to your home WiFi. When prompted, input your WiFi password into the Kinetic Secure Home app. The app will then generate a QR code on your device.</p> <p>5. Use the camera to scan this code. The camera will sound the voice prompt "QR Code Scanned."</p>	<p>Setup Instructions</p> <p>6. The camera will reboot to connect to your home WiFi. This process will take up to two minutes. When the camera's connection is successful, it will say "Setup Completed."</p> <p>7. Name your camera in the Kinetic Secure Home app.</p> <p>8. Repeat these steps for each additional camera, as prompted in the Kinetic Secure Home app.</p>
---	---	--	--	--	---	--	--



Scale 1:1 Unit:mm

型号: SAMC01WV3
规格: SAMC01WV3
-KSZP01 V1.0
物料编码:

产品名 ► scoutalarm摄像机说明书	印刷颜色 ► CMYK	物料材质 ► 105g无光铜	样品
设计于 ► 曹佳丽	成品尺寸 ► 60×50mm	特种工艺 ► 凤琴折	样品数量 ►