

Front View of the EUT



Back View of the EUT



View of the Top/Left Side of the EUT



View of the Bottom/Right Side of the EUT



View of the EUT with the Front Housing/PCB Removed



View of the Front PCB Housing Removed from the Mounting/System Interface Housing

