






1-N41-PC2-30-50-M-15-DFT-256QAM-Out
_Full-128@0-3000-18000-Ant1--36.83--25-P
ASS




1-N41-PC2-30-50-M-15-DFT-256QAM-Out
_Full-128@0-18000-26500-Ant1--42.55--25-
PASS




1-N41-PC2-30-50-M-16-CP-QPSK-Edge_1R
B_Left-1@0-30-1000-Ant1--61.70--35-PASS




1-N41-PC2-30-50-M-16-CP-QPSK-Edge_1R
B_Left-1@0-1000-3000-Ant1--41.95--25-PAS
S




1-N41-PC2-30-50-M-16-CP-QPSK-Edge_1R
B_Left-1@0-3000-18000-Ant1--36.75--25-PA
SS









1-N41-PC2-30-50-M-16-CP-QPSK-Edge_1R
B_Left-1@0-18000-26500-Ant1--42.70--25-P
ASS




1-N41-PC2-30-50-M-17-CP-QPSK-Edge_1R
B_Right-1@132-30-1000-Ant1--62.03--35-PA
SS




1-N41-PC2-30-50-M-17-CP-QPSK-Edge_1R
B_Right-1@132-1000-3000-Ant1--42.05--25-
PASS




1-N41-PC2-30-50-M-18-CP-QPSK-Outer_Ful
I-133@0-3000-18000-Ant1--36.58--25-PASS




1-N41-PC2-30-50-M-18-CP-QPSK-Outer_Ful
I-133@0-18000-26500-Ant1--42.44--25-PASS
S



1-N41-PC2-30-50-M-19-CP-16QAM-Edge_1
RB_Left-1@0-30-1000-Ant1--62.08--35-PASS
S




1-N41-PC2-30-50-M-19-CP-16QAM-Edge_1
RB_Left-1@0-1000-3000-Ant1--42.12--25-PASS
SS



1-N41-PC2-30-50-M-19-CP-16QAM-Edge_1
RB_Left-1@0-3000-18000-Ant1--36.84--25-PASS
ASS


1-N41-PC2-30-50-M-19-CP-16QAM-Edge_1
RB_Left-1@0-18000-26500-Ant1--42.42--25-PASS
PASS




1-N41-PC2-30-50-M-20-CP-16QAM-Edge_1
RB_Right-1@132-30-1000-Ant1--61.52--35-P
ASS







1-N41-PC2-30-50-M-20-CP-16QAM-Edge_1
RB_Right-1@132-1000-3000-Ant1--42.02--2
5-PASS




1-N41-PC2-30-50-M-20-CP-16QAM-Edge_1
RB_Right-1@132-3000-18000-Ant1--36.70--
25-PASS




1-N41-PC2-30-50-M-20-CP-16QAM-Edge_1
RB_Right-1@132-18000-26500-Ant1--42.36-
-25-PASS




1-N41-PC2-30-50-M-22-CP-64QAM-Edge_1
RB_Left-1@0-30-1000-Ant1--61.82--35-PAS
S



1-N41-PC2-30-50-M-22-CP-64QAM-Edge_1
RB_Left-1@0-1000-3000-Ant1--41.73--25-PASS
SS



1-N41-PC2-30-50-M-22-CP-64QAM-Edge_1
RB_Left-1@0-3000-18000-Ant1--36.87--25-PASS
ASS



1-N41-PC2-30-50-M-22-CP-64QAM-Edge_1
RB_Left-1@0-18000-26500-Ant1--42.36--25-PASS
PASS



1-N41-PC2-30-50-M-23-CP-64QAM-Edge_1
RB_Right-1@132-30-1000-Ant1--61.95--35-PASS
ASS

1-N41-PC2-30-50-M-23-CP-64QAM-Edge_1
RB_Right-1@132-1000-3000-Ant1--42.07--25-PASS
5-PASS