



CRAIG®

BLUETOOTH® STEREO HEADSET

Owner's Manual

PLEASE READ BEFORE OPERATING THIS EQUIPMENT.

Model: CBH511



FCC INFORMATION:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide residential protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on the circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE:

Changes or Modifications not expressly approved by the party responsible could void the user's authority to operate this device.

Location of Controls



1. ►► Skip forward Button
2. ◄◄ Skip backward Button
3. - (Volume Down) Button
4. + (Volume Up) Button
5. ► Play/Pause Button
6. ON/OFF Switch
7. LED Indicators
8. Mini USB Port (For charging only)
9. Built-in Microphone

Battery Recharge

The unit has a built-in rechargeable Li-polymer battery , recharge it before use as follow:

1. Connect the unit to the computer or any USB Charger by the supplied USB cable through the Mini USB port.
2. During charging , the Red indicator will light. When finished, it will turned off.

Notes: Your battery will last longer if you follow these simple guidelines for caring for and storing it.

- A. For first time charge, charge it approximate 12 hours.
- B. Recharge and store the device within the temperature range of 5°C~35°C (40°F~95°F).
- C. Do not overcharge (longer than 24 hours). Excessive charging or discharging may shorten the battery's life.
- D. Battery life naturally shortens slowly over time.

Operation








In first time use or re-pairing to new BT device, pairing the unit to external BT device as below:

1. Slide the ON/OFF Switch to ON position. Blue indicator will light and blinking .
2. Power on the external BT device and enter to searching mode. Start pairing as the on screen instructions on the external BT device. After paired, the Blue indicator will stop blinking. (For details, pairing procedures, please refer to the user's manual of your BT device).

Notes:

- ~ When the external BT device searched the unit, our model number "CBH511" will appear on the display of external BT device.
- ~ Pairing code "0000" or "1234" may need to enter.

Normal operation after pairing:


1. Turn on the BT function of the external BT device.
2. Slide the ON/OFF Switch to ON position to power on the unit. Wait until the Blue Indicator is light and stop blinking. (It needs take a few seconds).
3. Plays the music in the connected BT device as usual.
4. During playback:
 - Press the  /  Button to skip the tracks.
 - Press the  /  Button to adjust volume level.
 - Press the  Button to pause, press again to resume.
5. If the unit is paired to Cell Phone:
 - When a call is incoming during listening, press the  Button to hook off then speak to the built-in microphone to answer the phone. When finished, press the  Button to hook on then resume to music playback.
6. When finished listening, slide the ON/OFF Switch to OFF position to shut off the unit.

Troubleshooting:

Can't be power on	Battery consumed	Recharge the battery.
No sound	Volume was set to minimum level	Increase the volume by press + Button.
Sound distortion	Volume or Bass level too high	<ul style="list-style-type: none">• Reduce the volume level by press the - Button.• Reduce the volume and/or bass level of the connected Player.

Specification:

Power source:Built-in rechargeable Li-polymer battery. Recharge by

DC  5V through Mini USB Port.

Impedance of Earpiece:32 Ohm, 100mW

Audio Power.....100mW

Accessories:

1 x User's Manual

1 x USB Connection Cable (for charge only)

LIMITED WARRANTY

Craig warrants this product to be free from manufacturing defects in material and workmanship under normal use for a period of 90 days from date of purchase. If service is required, please return the product to the store where it was purchased for exchange; or, pack the unit in the original packing material with all accessories if applicable, a copy of your sales receipt and a Cashier's check or Money Order for \$7.00 (to cover shipping and handling costs) payable to Craig Electronics Inc. For consumers in Canada, please make sure that the cashier check or money order is redeemable through a U.S. bank. Ship your product freight pre-paid. Your unit will be repaired, replaced or if the unit can not be repaired or replaced, a refund will be forwarded to you within four weeks of receipt of your unit. Please ship your unit to:

Craig Electronics Inc.
1160 NW 163 Drive
Miami, FL 33169

This warranty is void if the product has been: a) Used in a commercial application or rental. b) Damaged through misuse, negligence, or abuse. c) Modified or repaired by anyone other than an authorized Craig service center. d) Damaged because it is improperly connected to any other equipment.

Note: This warranty does not cover: a) Ordinary adjustments as outlined in the Owner's Manual which can be performed by the customer. b) Damage to equipment not properly connected to the product. c) Any cost incurred in shipping the product for repair. d) Damage to the product not used in the USA.

This warranty is not transferable and only applies to the original purchase. Any implied warranties, including the warranty of merchantability, are limited in duration to the period of this expressed warranty and no warranty whether expressed or implied shall apply to the product thereafter.

Under no circumstance shall Craig be liable for any loss or consequential damage arising out of the use of this product. This warranty gives specific legal rights. However, you may have other rights which may vary from state to state. Some states do not allow limitations on implied warranties or exclusion of consequential damage. Therefore, these restrictions may not apply to you.

To Obtain Service on your Product
email: service@craigelectronics.com