



QUICK START GUIDE

IN-RACE APP GUIDE.....	4
PIT LANE GUIDE.....	5
POWERBASE GUIDE	6
CONTROLLER GUIDE	8
QUICK START GUIDE:	
STAGE 1 - DOWNLOAD APP	9
STAGE 2 - CONNECT POWER	10
STAGE 3A - CONNECT CONTROLLER	11
STAGE 3B - CONNECT CONTROLLER	12
STAGE 3C - CONNECT CONTROLLER	13
STAGE 4 - CONNECT APP.....	14
FEATURE LIST.....	15
LED BEHAVIOUR	18
TROUBLESHOOTING	19

Hornby Hobbies Limited
Westwood
MARGATE
Kent CT9 4JX
United Kingdom

Tel. +44 (0) 1843233525
customer@hornby.com

www.scalextric.com

DRIVER ICON

- Pre-selected driver icon
- Incident on track, pit-stop required




DRIVER NAME




PREVIOUS LAPS

- Displays your fastest lap
- Displays your previous lap

BEST LAP 00:01.950
LAST LAP 00:02.349

KERS

When activated KERS will build up and can be used as a speed boost

FULL LOW EMPTY

DRIVER PLAQUE

DRIVER COLOUR



LAP & TIMES

On-Track:

- Number of laps completed
- Race Timer

LAP 008/050
TIME 00:51.903

In the pits:


- Length of time for the pit stop
- Number of laps behind leader

PIT IN 00:03.033
+ 0 LAPS

TYRES

When tyre wear is activated the grip levels will fall until you have a blow-out, slowing your car









100% GRIP <30% GRIP <10% GRIP ZERO GRIP (FLASHES)

FUEL

When activated fuel load will decrease each lap

100% <30% <10% EMPTY (FLASHES)

**KEY:**




- Ⓐ Start behind this line
- Ⓑ Lane 1 Pit Box
- Ⓒ Lane 2 Pit Box
- Ⓓ Timing Sensors
- Ⓔ Car ID Sensor (RCS PRO™ only)


Please note:

It is important that you start behind the line shown at Ⓐ This will ensure that the sensors are not triggered before the start, which could cause incorrect false start penalties.

KEY:

- A** Power & Bluetooth LED
- B** USB Socket
- C** Rectangular Power Socket (RCS ONE™ & RCS AIR™ only)
- D** Power Jack Sockets (RCS PRO™ only)
- E** Controller Sockets (RCS ONE™ only)
- F** Binding Buttons (RCS AIR™ & RCS PRO™ only)
- G** Binding Indicators (RCS AIR™ & RCS PRO™ only)



**KEY:**

- Ⓐ Power Switch
- Ⓑ Power/ Bluetooth LED
- Ⓒ Trigger
- Ⓓ Battery Screw
- Ⓔ Battery Door
- Ⓕ Lanyard Loop
- Ⓖ Lane-Change Button (RCS PRO™ only)
- Ⓗ Brake Button (RCS PRO™ only)

QUICK START GUIDE

- ❶ Download and install the App from Google Play or the iTunes App Store.
- ❷ Enable Bluetooth on your device.
- ❸ Follow the track layout instructions (provided in your set).

