



Label



Label location



The label is attached to the surface of the shield with a permanent adhesive.