



WHAT'S IN THE BOX

Wireless Bluetooth Speaker



USB Cable for charging



AUX Cable



PAIRING WITH A BLUETOOTH DEVICE

Make sure the mobile device (Mobile phone, tablet, computer, etc.) you are trying to pair the Bluetooth Speaker with supports Bluetooth. Specific pairing procedures may vary depending on the mobile device you are trying to pair with, for detailed information on using the Bluetooth function of your mobile device, please refer to the mobile devices user guide.

1. Power on the Bluetooth Speaker, Slide the "On/Off Switch" to the ON position, the speaker will speak "The Bluetooth device is ready to pair" The Bluetooth Speaker is now in pairing mode
2. On your mobile device, navigate to Settings>Bluetooth and search/scan for "Tech2 Rainbow" (some mobile devices will begin to search automatically) and select it.
3. Sometimes your mobile device may confirm you want to connect to "Tech2 Rainbow" select "yes" or "enter" to complete the pairing process.

Depending on the mobile device you are trying to connect the speaker to, it may be necessary to enter a passcode. If so, enter "0000".

The Bluetooth Speaker will automatically reconnect to your mobile device when they are powered on and in Bluetooth range

CONNECTING WITH OTHER BLUETOOTH DEVICES

The Bluetooth Speaker can only be connected to one Bluetooth device at a time. To pair the Speaker to a different device (other than the device originally paired with) you must first close the initial Bluetooth connection on the first device, either by shutting off the Bluetooth function, or if the device is out of range, it will be automatically disconnected. Then proceed to pair with the desired device using the previous steps for "Pairing with a Bluetooth Device".

When the unit is connected and paired to your device.

- Press the "Play/Pause" (M) button to start playing music or navigate to the music app on your mobile device and select a media file to begin playing.
- Quick press the "Next" or "Previous" buttons to skip to the next or previous track.
- Press and hold the "Next" or "Previous" buttons for volume control.
- Press the "Light" button on the speaker to alternate between different light modes.

You can also control the volume using the volume controls on your mobile device. For maximum volume output make the sure the volume on your mobile device is set to the loudest setting.

PLAYING MUSIC

CHARGING

Attach the included Micro USB cable (smaller end) to the Micro USB charging port of the Bluetooth Speaker, and plug the other end of the cable into a USB charger or USB port on your PC. If the battery is completely dead it will take up to 1.5 hours to fully charge the device.

The charging indicator light will illuminate red when the unit is charging.

FCC STATEMENT

DECLARATION OF CONFORMITY WITH FCC RULES FOR ELECTROMAGNETIC COMPATIBILITY
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Federal Communications Commission Notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

WARRANTY

Bayit Home Automation Corp. ("Bayit") warrants to the original purchaser of this Tech2 product that the product shall be free of defects in design, assembly, material, or workmanship. Bayit warrants the Tech2 product for one (1) year for devices bought in U.S.

Product Warranty Bayit will repair or replace, at its option and free of charge (except for shipping charges for the product) any defective Tech2 product. Bayit reserves the right to discontinue any of its products without notice, and disclaims any limited warranty to repair or replace any such discontinued products. In the event that Bayit is unable to repair or replace the product (for example, because it has been discontinued), Bayit will offer either a refund or a credit toward the purchase of another product in an amount equal to the purchase price of the product as evidenced on the original purchase receipt as discounted by its natural use or offer a similar product at Bayit's discretion. No warranties will be honored unless the purchaser provides, at purchaser's expense, the product for inspection. No warranties will be honored if Bayit determines that the product has been improperly installed, altered in any way, or tampered with. The Bayit Product Warranty does not protect against acts of God such as flood, lightning, earthquake, war, vandalism, theft, normal-use wear and tear, erosion, depletion, obsolescence, abuse, damage due to low-voltage disturbances (i.e. brownouts or sags), non-authorized program, or system equipment modification or alteration.

Bayit reserves the right to review the damaged Tech2 product. All costs of shipping the Tech2 product to Bayit for inspection are the sole responsibility of the purchaser. If Bayit determines, in its sole discretion, that it is impractical to ship the damaged product to Bayit, Bayit may designate, in its sole discretion, an equipment repair facility to inspect and estimate the cost to repair such product. Any cost of the estimate or shipping the product to and from a repair facility is the purchaser's responsibility. Damaged product must remain available for inspection until the claim is finalized. Whenever claims are settled, Bayit reserves

the right to be subrogated under any existing insurance policies the purchaser may have.

THIS WARRANTY CONTAINS THE SOLE WARRANTY OF BAYIT. THERE ARE NO OTHER WARRANTIES, EXPRESSED OR, EXCEPT AS REQUIRED BY LAW, IMPLIED, INCLUDING THE IMPLIED WARRANTY OR CONDITION OF QUALITY, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND SUCH IMPLIED WARRANTIES, IF ANY, ARE LIMITED IN DURATION TO THE TERM OF THIS WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. IN NO EVENT SHALL BAYIT BE LIABLE FOR INCIDENTAL, SPECIAL, DIRECT, INDIRECT, CONSEQUENTIAL OR MULTIPLE DAMAGES SUCH AS, BUT NOT LIMITED TO, LOST BUSINESS OR PROFITS ARISING OUT OF THE SALE OR USE OF ANY BAYIT PRODUCT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. This warranty gives you specific legal rights, and you may also have other rights, which may vary from state to state. Some states do not allow the exclusion or limitation of incidental, consequential, or other damages, so the above limitations may not apply to you.