


**Installation Guide** 

# **SOUNDSHAKER AMPLIFIER SETUP** This is the main amplifier setup. Please follow each to step to ensure that your amplifier is installed correctly. Name: Digital Amplifier with Receiver Model No. 81-5102 Sound Shaker Amplifier (Rear Plate) 81-5102 AUDIO-IN 15V DC **STEP 1. CONNECT MAIN CABLE TO AMPLIFIER** Main Cable 81-3120 connects to 'TRANSDUCER' port on back of Soundshaker Amplifier 81-5102. 1 STEP 2. CONNECT MAIN CABLE TO SHORT CABLE Main Cable 81-3120 connects to Short Cable 81-3108. 81-3120 81-3108 (2) (3 Connect Power Supply 81-5465 to 15V DC Port on the back of 81-2887 Soundshaker Amplifier 81-5102. STEP 3. CONNECT SHORT CABLE TO TRANSDUCER Transducer Short Cable 81-3108 connects to Transducer 81-2887. 81-3120 81-3108 (3) 81-2887 Transducer 81-3120 2 **3** 81-2887 Transducer 81-3120 81-3108 **3** 2 81-2887 Transducer


## SOUNDSHAKER TRANSMITTER SETUP

This is the transmitter setup. Please follow each to step to ensure that your transmitter and amplifier are connected correctly.



## SOUNDSHAKER WIRELESS SYNCING

Time to svnc vour transmitter and amplifier. Please follow each to step to ensure that your equipment svncs correctly.



# STEP 1. HOLD TRANSMITTER CODE BUTTON TO BEGIN SYNC WITH AMP

With an audio signal present, press and hold Code Button for a minimum of 3 seconds to begin syncing process. When light blinks rapidly proceed to step 2.



#### STEP 2. HOLD AMPLIFIER CODE BUTTON TO COMPLETE SYNC

Make sure Wireless Switch is set to ♥ Press and hold Code Button for a minimum of 3 seconds until light blinks rapidly. Red light will turn solid when pairing is completed. (Both units should have solid red lights when paired.)

Sound Shaker Amplifier (Front Plate) 81-5102

# SOUNDSHAKER BLUETOOTH SYNCING

Please follow each to step to ensure that your equipment syncs correctly.

