

M&M SPEAKER

OPERATION INSTRUCTIONS:


1. Switch on the M&M speaker using the on/off button located on the back of the speaker.
2. LED light will turn on and automatically go into pairing mode
3. Pair your mobile device by turning bluetooth on, "M&M SPEAKER" will appear. Sync and enjoy!
4. Use your external device to change volume, song choice etc...

NOTE: ENSURE THAT YOUR M&M SPEAKER IS SWITCHED OFF WHEN CHARGING

5. To fully maximize the battery life, use the battery fully before recharging and charge the speaker before playing.
6. Pause/Play- Pickup Calls- Press the small button to pause/pick a call or play music.

Battery Capacity: 300 mAh

Input Voltage (power supply): DC5V



®/™/© 2016 MARS and its affiliates.

Under License by Zeikos, Inc. © 2016 Zeikos, Inc. 19 Progress Street, Edison, NJ 08820. iHip is a trademark of Zeikos, Inc. All Rights Reserved. For ages 12+. This is NOT a toy or candy. Manufactured in China. This product contains chemicals known to the state of California to cause cancer and/or birth defects or other reproductive harm.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.


Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: CHANGES OR
MODIFICATIONS TO THIS UNIT
NOT EXPRESSLY APPROVED
BY THE PARTY RESPONSIBLE
FOR COMPLIANCE COULD VOID
THE USER'S AUTHORITY TO
OPERATE THE EQUIPMENT.



Bluetooth Speaker Operating instructions