

Ξ界面	<u>⊹</u>	亮度减 截屏 [●]	÷: •	亮度加触摸板开启/关闭	滑动手指	移动光标	单指敲击	鼠标左键
建盘	 	上一曲	►II	播放/暂停	○ →		00	
H	=	静音	■)	音量减	单指快速双	左键选中 目标拖动		鼠标右键
1	<u></u>	锁屏	0	蓝牙配对	击不松拖动		双指敲击	
È	**	输入法切换		背光亮度调节	双指垂直/	滚轮垂直/ 水平滚动	000	*截屏 (适用于有Home键的机
小行首	end	光标到行尾	pgup	往上翻页	水平移动		三指敲击	
羽页					III	最近任务	îîî	返回主界面
in键组合实现					三指同时 向上移动	窗口切换	三指同时 向下移动	~
分短按与长按,以适应不同机型 F有Home键的机型 用于无Home键的机型					←000→	活动窗口 左/右滑动	0000	* 截屏

iPad OS鼠标功能开启:"设置" ---"辅助功能"----"触控" ----"辅助触控"

四指敲击

① 注意:

1.在长期不使用时,我们建议关闭键盘,以延长电池的寿命。 2.为了获得更长的电池使用寿命,建议电源灯闪烁时才给键盘充电,每次 充电时间最好不少于2小时。

节能休眠模式

当键盘15分钟内无任何操作,将会自动进入休眠模式,所有LED都会 关闭,需要使用时,只需要按任意键并等待3秒左右,键盘将会被唤醒并 自动连接蓝牙,就可以进行正常工作。

故障清理

1.确定已开启电源 2.确定键盘在可操作的距离范围内 5.确定无线键盘和蓝牙连接 3.确定电池蓄有电量

4 确定平板电脑的蓝牙设置已打开

6.确定无线键盘与蓝牙已配对

清洁

用清水,酒精或类似酒精的消毒剂清洁键盘。

当电池电量低时,低电量指示灯会不断闪烁,这时需给键盘充电 1. 将原装附件USB线Type C端连接到键盘上的充电接口

2. 将USB线A端连接到电源适配器或电脑USB接口(电源适配器不包括)

3. 键盘充电过程中, 充电指示灯会长亮, 充满后自动熄灭

禁止此类限制的情况除外。

(1) 意外事件、误用、操作不当或任何未授权的维修、改装或者拆卸; 2)操作或维护不当,使用过程中违反产品说明或连接不适当的电源; (3)或者使用并非本公司提供的消耗品(如备用电池),但适用法律



- Caps Lock indicator: Lights up when the keyboard is in uppercase input. Low battery indicator: flashes when the battery is too low, prompting to charge. - Charging indicator: It will light up when charging, and will be off after charging is completed. ලා 🖟 🗋 💈 0 0 0 0 USB TYPE C Charging Port: When the low battery lights on ,please use the Original charging cable to — Switch

- Pen slot Split power point

5. Discover the Bluetooth keyboard device: Bluetooth Keyboard 5.0 Qx, and click on it, the Bluetooth keyboard will automatically connect.

6. After the Bluetooth connection is successful, the pairing indicator is

off, and "Connected" will appear in

the list of Bluetooth devices.

	Back to Home page	- <u>;</u> ¢;-	Brightness -	, o(-	Brightness +
Q	search	×	Screen capture	Ø	Touchpad on/off
	Screen keyboard	i44	Previous track	►II	Pause/Play
▶	Next track	•	Mute Key	■)	Volume-
()	Volume+	<u></u>	Lock screen	@	Bluetooth pairing
Fn	Function key	-	Input method switching	-\$-	Backlight 9 brightness adjustment
home	Home	end	End	pgup	Page Up
pgdn	Page Down				

he above function keys need to be combined with the FN key.

Note 1: Screen capture function is divided into short press and long press to adapt to different models


Short press: for models with Home button Long press for 2 seconds: for models without Home button

Note 2: This button is only available on the backlit version of the keyboard.

Color adjustment: direct click, a total of 7 color cycles.

Brightness adjustment: Fn combination button, a total of 3 brightness cycle

IOS13 system touchpad gestures



iPad OS mouse function is enabled: "Settings" - "Accessibility" - "Touch" -"Auxiliary Touch" - "Open"

(!) Attention

1. When not use for long time, suggest to close keyboard, in order to prolong battery lift. 2. In order to get longer battery lift ,charging before keyboard power light flashes, charging time must be better more than 2hours.

When keyboard not use will be enter sleep mode after 15minutes, keyboard indicator will off, press any key 5s to wake it up when need use again ,then keyboard indicator

1. Make sure the power is turned on 2. Ensure keyboard operable distance

3. Make sure the battery has power 4. Ensure the device's Bluetooth was turned on

5. Ensure the wireless keyboard was connected with the Bluetooth 6. Ensure the wireless keyboard paired successfully

Washing, alcohol or a similar cleaning agent decontamination keyboard.

When battery is low, the power indicator blinking, means need to charge the keyboard Connect Genuine Parts USB cable B port to keyboard cradle

2. Connect USB cable A port to power adapter or computer USB port.

3. When charging, charge indicator lights will blinking, after full lights automatically

保修卡

用户填写资料

通讯地址 ___

购买日期_

公司或个人全称_

所购产品名称及型号_

本有限质保不涵盖由于以下原因导致的问题或损坏:

Warranty Card

Company or personage full name

User information

Contact address

TEL_____ Zip____

The purchased product name and model NO.

Purchased date

include on the warranty.

1) Accident, misuse, improper operation, or any unauthorized repair, modified or removed.

2) Improper operation or maintenance, when operation violation of the instructions or connection unsuitability power supply.





FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.