Network license no.: screen, screen HD, dreamlike appearance,

CMIT ID: streamline shape, taste different.

Thank you for choosing

HV7-CV718intelligent tablet computer.

HV7-CV718 is based on

a fashion intelligent tablet

computer Android ™ operating

system, equipped with 7

inch high-definition

The HV7-CV718 is designed for WCDMA/GSM

network dual-network dual

standby intelligent tablet computer, using

the latest Android ™ 4.4.2 system, with

strong quad-core processor, the

industry high-end

performance guarantee perfect experience

.7 inch screen, reducing the nature pure bright colors; HV7-CV718 new design more concise interface, desktop exquisite small parts, perfect to decorate your personalized desktop; HV7-CV718 exclusive special software, call

management, books will be an easy job to. Shine HV7-CV718 worth you savor! Do not use any root tool of the tablet computer, otherwise there may be failure can not be restored, the root tablet computer did not enjoy the warranty! Please read the manual carefully before use.

Directory	Favorite 12
understand the standby	Contact 13
function	
Browser11	
E-mail1	
Clock1	2 Information13
Calendar 1	2 Camera 13
Dial1	
Dial 1	
Record1	

Music14	Profiles 16
Film Studios15	Display 16
Set up 15	To store information 17
SIM card management 15	Battery17
WLAN 15	Application17
Bluetooth 15	Location-based services 17
Traffic usage15	Security 17
More settings15	Language and input method17

	Reset 18	Recorder	20
	Accounts & sync18	Calculator	20
	Date and Time18	Download content	20
	Timer switch 18	Google	20
	Auxiliary functions 18	Voice Search	21
	Developer Options19	Gmail	21
	Tablet PC19	Play market	22
Docui	ment Management19	Google map	22
Radio	20	Google Setting	22

Understand the standby function	
FCC Caution	24
Hangouts	24
News&Weather	24
Youtube	23
Play music	23

Flat computer is in standby mode, can see the standby screen. In the standby screen, can view the tablet computer and access application.

The standby screen by default has 5

panels. Scroll left or right to choose a standby screen panel. Can also choose to the bottom of the screen to the standby screen panel corresponding to move directly.

Press and hold the power button function

- Shutdown: Perform a shutdown
- 2. Flight mode: turn on or turn off airplane mode
- 3. Restart: Restart the operation execution
- > Choice wallpaper

You can set the wallpaper from the

definition of the stand by screen or lock

Wallpaper: set the background image.

Wallpaper: can set wallpaper

Video Wallpaper: set the

background video.

Album: you can select an

album pictures set as wallpaper.

Moving Projects on the standby screen

Click and tight hold the items to move. In the project after vibrating drag the item to the desired position.

> Removes Projects form the standby

screen

Click and press and hold to remove a project, project of vibration and application areas will display the Recycle Bin icon, indicating that the application area of the bottom of the screen to the recycle bin.

Drag the item to the recycle bin.

When the project becomes red, loosen the project

> use shortcuts panel

Use the application in standby

mode or touch the top of the

screen, indicator icon, then drag down the finger, open the shortcut panel. You can activate or deactivate the wireless connection and other functions, the list and access the notification such as information, communication, activity or process state. If you want to hide the

list. please refer to the next

frame dragging the list.

Sliding around shortcut icon, you can use

the following options in the shortcut panel:

- Owner: Go to the machine main information interface
 - Battery: Check battery percentage, you can click into the cell interface.
 - ♦ settings: Go to Settings interface
- ♦ WLAN: activate or deactivate the

WLAN connectivity. Click the icon to enter long WLAN settings interface.

- Bluetooth: Activate or deactivate the Bluetooth wireless connectivity.
- GPS: activate or deactivate the GPS.
- flight mode: activate or deactivate the flight mode.
- data connection: open or close the data connection.
- ♦ traffic usage: View traffic usage
- profile: You can set the standard, mute, conference.
- ♦ Brightness: adjust the screen

brightness.

- Automatically turn the screen: enable or disable the Auto-rotate screen function.
- projection screen: Click to enter the setup screen projection

Widaets

Long press the standby interface, select widgets, select any one of widgets long press and drag to standby. Customized according to personal

preference tablet can achieve more.

Set the current time and date

In standby mode, open the application list and select Settings → Date and time.
Set the time and date and change other

options.

Change the ringtone

In standby mode, open the application list and select Settings \rightarrow Profiles \rightarrow Standard \rightarrow voice ringtones or message tones.

Select a ringtone from the list, then select OK

Choose wallpaper for the idle screen

- In standby mode, press the standby interface will pop up wallpaper → Select wallpaper sources.
- 2. Select the image.
- 3. Set as Wallpaper.

Adjust the display brightness

Adjust the screen brightness in the settings

menu.

- 1. In standby mode, open the pull-up bar, and then select Settings \rightarrow Display \rightarrow Brightness.
- 2. Adjust the screen brightness

Set Voice Unlock

You can set voice unlocked to prevent unauthorized use of the Tablet PC.
Select Settings → Security → Speech →
Entry unlock command (command containing 2-6 words to say, and then repeat 3-6 times)

After successfully set, lock screen, when you unlock, unlock using voice

Browser

Understanding of web access preferences and add to bookmarks.

Browse the web

In standby mode, open the application list, and then select the browser to launch the specified Home.

For access to a specific page, select the URL input field, enter the Web address, and then press the Enter key on the keyboard or click the Search icon. E-mail

By configuring the personal or corporate e-mail account, send or receive e-mail with

the Tablet PC.

Configure e-mail account

- In standby mode, open the application list and select Email.
- Select an account type, and enter
 your e-mail address and password
 Select Next (for regular e-mail account)
 or manually configure (for other company
 email accounts).
 - Follow the on-screen prompts to operate. After the e-mail account settings, e-mail messages will be downloaded to your Tablet PC.

Clock

You can set the alarm.

Note: support the shutdown alarm clock.

Calendar

You can view the date, set Calendar easy to use.

Dial

Dial

Learn how to use the call function, such as through the options available to make and receive calls during a call, or with call-related functions to customize and use.

Record

You can view the call records by type screening.

- In standby mode, click the dial key to switch to the phone records.
- Resource type in the call log interface, according to the type of phone can also be classified call records.
- 3. To view detailed call details records.

Favorite

All have the number of contacts (including Tablet PC and SIM card numbers of all contacts).

Contact

Learn how to create and manage personal or company contact list stored on the Tablet PC memory or SIM or USIM card. Can save the contact's name, number of tablet PCs, home phone number, e-mail addresses and more information.

Groups

Set a contact group.

Favorite

For collection of certain contacts, regular contact,

Note: Only the Tablet PC contacts in

order to use the collection function.

Contact

Contains all of the contacts on the Tablet PC, SIM card $_{\circ}$

Information

Learn how to create and send text messages (SMS) or multimedia message (MMS), as well as view and manage the information sent or received. Send or receive information in the local service area may incur additional charges For more information, contact your service provider. Camera

Standby mode, from the application to

enter into the camera executable photographs, video functions. Camera to take high-quality photos, more professional camera mode supports continuous shooting, special effects, etc., support to shoot high-quality video.

Album

Learn how to view pictures and play the video store the memory card and Tablet PC.

Video player

Learn how to view saved in the memory card long press on a video file can 14

be as follows: Share, delete, rename, and here for details.

Music

Learn how to use the music player to player to listen to their favorite music. The music player supports the following file formats:: aac, amr, ape, flac, imy, m4a, mid, mp2, mp3, ogg, way.

· Add music

Add files to the device: 1.

Downloaded from the wireless Web

2. through the data line copy or via

Film Studios

Can use to edit your favorite pictures and music video.

Set up

SIM card management

This feature can choose to turn off or the SIM card; choose to call the video phone SIM card; Select the data connection is open and international roaming; view SIM card applications.

WLAN

Set the state of the WLAN network notice, to

add network.

Bluetooth

Set Bluetooth status, search for Bluetooth devices, modify Bluetooth name and the Bluetooth sharing networks, etc. can be used.

Traffic usage

To view SIM flow use.

More settings

 This feature set flight mode, vpn, network sharing and portable hotspot, mobile network, GPRS priority mode.

Profiles

Set the Tablet PC ringtones, information ringtone and volume, but can also set a custom profile.

Display

Set with flat-panel computer display related functions, such as the theme switching, select the lock screen style, adjust brightness, set wallpaper, automatically rotate the screen, set the sleep time,

information and contact the font size, the level of implementation of calibration.

- 2, New Clear Motion function, use this feature to enhance the fluency of the video.
- MHL settings: Use MHL function can be linked with the TV side, wired transmission.
- projection screen: functionally equivalent MHL, but the realization of wireless transmission.
- 5, minimalist theme: You can switch themes.

To store information

Check the memory card and the tablet computer storage on storage conditions, you can format the memory.

Battery

Display the charging status and percentage; battery time and display electricity.

Application

Change install the application management settings.

Location-based services

View location using a wireless network

in the application.

Security

You can set various password used to protect the tablet PC, to prevent unauthorized use.

Note: PIN code initial password is 1234.

Language and input method

- You can select a language, set the keyboard to select the input method.
- Voice Control: Open Voice control calls, use a headset, you can answer the call and reject a voice call. Open voice camera, you can use voice photographed.
 Open the alarm clock, you can use voice

control for alarm.

Reset

Restore the factory default settings will erase all data on the Tablet PC, please exercise caution.

Accounts & sync

Change the automatic synchronization feature set or manage the account you want to sync.

Date and Time

Can be set to display the date and time of the Tablet PC.

Timer switch

Open the Tablet PC based on user habits timer switch function.

Auxiliary functions

- 1. After you turn on the power button, press the power button to end a call $_{\circ}$
- Gestures: Close the application, screenshots, music, switching control, backlight control.

 Subtitle: Download video and corresponding subtitle file, you can use the subtitle function.

Developer Options

Developers to use.

Print

Install the print services such as Google's Cloud Print.apk

You can then use the print function in photo albums.

Tablet PC

For information about the Tablet PC, check the status of the Tablet PC.

Document Management

Learning fast and fun to open all your pictures, videos, music, documents, and other types of files stored on the tablet computer storage and SD card.

Note:

- Except for MP3, MP4 or image files, please don't move or delete system files in SD card:
- it's suggested to install the SD card APK installation package.
- 3 if you want to replace the card, please copy the data to the new card, otherwise it will cause the entertainment function.

of the machine can not be the used normally.

Radio

Listen to radio programs on the radio when you can listen to your favorite recordings.

Recorder

Help you quickly save the voice recording, you can set your favorite sound quality and recording mode, choose the storage location.

Calculator

Learn how to perform mathematical calculations directly on the Tablet PC, like an ordinary hand-held or desktop calculator, horizontal screen switch to a scientific calculator.

Download content

Management through the browser to download the content.

Google

Through the Google search can be accurately positioned your demand function, while Google support voice recognition function, click on the speech recognition, search for information through voice input, allowing users to use more convenient.

Voice Search

Google Voice Search is a U.S. company
Google launched a new search product,
added a voice search function. The new
version of Google voice search applications
allows users faster and easier for web
search. Search applications, the added
voice search function have been improved.
Do not have to manually enter, simply say

you want to query, you can quickly get a voice answered. In addition, the application of voice recognition function can be strengthened.

Gmail

list and select Email.

by creating a Google email account, use flat computer to send or receive e-mail.

- In standby mode, open the application
- 2. Select the account type, and enter your email address and password.
- Select Next (for general email accounts)or manual configuration (for other company

email accounts). Follow the screen prompts.

After the completion of the e-mail account settings, e-mail messages will be downloaded to your tablet.

Play market

Play Store is the world's largest Android software and games download platform, to provide users with a good Tablet PC software services

Google map

Can accurately locate the current position and access lines, and around the bus station, restaurants, gas stations, ATM, cinemas, hotels, food, etc...

Google Setting

google settings icon is after google play (Google store) updates automatically installed, belonging Google framework of a program, its benefits is that you can click into the advertising option is turned off, so that through the Google application of official advertising push ads does not have.

Play music

An official from the Android 4.0 system comes with a music player, a new player, using a very simplified interface design. deliberately atomized background; addition to changing the appearance of the interface, the future of music player (or other) operation is also possible to go the direction of the whole software keys, but also to the options screen all operations more transparent, intuitive, easy to operate some!

YouTube

YouTube as the most successful in the current industry, the strength of the most powerful and influential quite widely online video service providers. YouTube's system on a daily basis to deal with thousands of video clips, providing a high level of thousands of users worldwide video upload. distribute, display, browsing service. Through strong technical support, YouTube provides support for multiple formats of video content, and to upload a file specification shall also put relatively open, the capacity does not exceed 2G, and the

length of no more than 15 minutes of video are here allowed. (Java upload tool can be a size limit raised to 20G, and support for HTTP)

News&Weather

Learn the news and the weather from the internet.

Hangouts

Connect to the network, log in Gmail, you can add contacts, then you can use this to send messages.

FCC caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including

interference that may cause undesired

operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and

found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to

provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in

a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving

antenna

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information:

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although

the SAR is determined at the highest certified power level, the actual SAR level

of the phone while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output. Before a new model phone is a available for sale to the public, it must be tested and certified to the ECC that it does not exceed the exposure limit established by the FCC, Tests for each phone are performed in

positions and locations (e.g. at the ear and worn on the body)as required by the FCC. For body worn operation, this model phone has been tested and meets the ECC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that Contains no metal and that positions the

handset a minimum of 1.0 cm from the

body.