



XBS958 User Manual

Product Introduction

The product is a kind of portable desk-type Bluetooth speaker. It adopts digital signal processing technique, and is applicable to office, home and other different environments and can wirelessly connect with most of other equipment and mobile phone with Bluetooth function to play high quality music.

Notice

Read this instruction manual carefully before using to ensure proper use of the product. In order to maintain good performance, do not use the product in dusty or wet environment, especially under the following conditions:

1. Wet place or underwater operation
2. Heater or work in hot environment
3. Under direct sunlight
4. In the place where it's easily to fall off
5. Do not disassemble the speaker without permission, or otherwise the warranty would be invalid.

Warning

- 1. The apparatus shall not be exposed to dripping or splashing.
- 2. To avoid fire or electric shock, please check whether network voltage is consistent with rated voltage of the product.


Accessories

- Bluetooth Speaker x 1
- User Manual x 1
- MICRO USB cable x 1



Panel Introduction

- 1 ● Microphone position of handsfree calls.
In order to keep normal connection quality, the user is preferred to make a call in 1 meter away from the machine.
- 2 🔍 Short press to decrease volume and long press to decrease volume fast.
- 3 ⏸ In Bluetooth play status, short press the button to pause and play music; when a call comes, short press the button to answer and hang up.
- 4 🔍 Short press to increase the volume and long press to increase the volume fast.



1. LINE OUT: Audio output
2. AUX IN: For external audio input (Specifications: 3.5 plug)
3. •: Red indication
4. USB: MICRO USB socket
5. ON OFF: Power switch

Indicators:

LED (Blue): In Bluetooth connecting pairing process, the blue LED will blink; after pairing, the blue LED will be on. (right forward of the machine)

LED (Red): It will turn on Line-in function with inserting the line-in wire. And the red LED will be on.

LED (Red): In the charging process, the red LED will be on, when battery is full, the red LED will go out. (the back of the machine)

Operation description

Power on: Change the switch on the back of the machine to ON position.

Power off: Change the switch on the back of the machine to OFF position.

Charging: 1. Connect USB line into the PC and insert the other end in MICRO USB socket in the back of the machine to charge for lithium battery.
2. Power adapter with DC 5V output is also available for normal charging of the machine.

Pairing: 1. When using for the first time, Blue LED indicator will blink to enter pairing mode.
2. Activate the Bluetooth function to make the mobile phone start to search for Bluetooth device, select the searched device named XBS958.
3. If you're required to enter password, enter "0000" and press ENTER key to start pairing. After successful pairing, the blue lamp will flash regularly and with a beep.

Remark

1. When the paired equipment number exceeds the maximum capacity 4 units, the product will automatically clear the first equipment in its memory.
2. Once paired, the speaker will enter connection mode.
3. If disconnection is needed, long press ⏸ or select disconnect in the mobile phone.

Handsfree call answering:

In Bluetooth music play mode, when a call comes, the loudspeaker will send telephone ring, short press ⏸ to answer the call.

Hang up the call:

In handsfree mode, short press ⏸ to hang up the call to return to the Bluetooth music play mode.

LINE IN play mode:

When the machine plays music in Bluetooth mode, connecting line-in cable to AUX IN socket, the system will automatically enter AUX IN mode.

Unplug the line-in cable from LINE IN socket to automatically enter Bluetooth mode.

LINE OUT play mode:

When the machine plays music in Bluetooth mode, use 3.5 mm audio cable to insert LINE OUT socket of the machine, at this time, the machine audio source will be through the other end of the output audio cable.

Specifications

Bluetooth specification:	Bluetooth V3.0
Bluetooth distance:	Maximum connection distance10m
Power output:	1.5W×2
Operating frequency range:	2.402GHz ~ 2.480GHz unlicensed ISM band
Supported profiles:	HFPV1.5, A2DPV1.2, AVRCPV1.0
Speaker impedance:	L, R: 4Ω
Dimension:	(L)154×(W)54×(D)56 mm
Weight:	Approx. 295g

Troubleshooting

LED indicator lamp does not work, Bluetooth cannot be connected

The Bluetooth device has entered sleeping mode due to long time of no-operation. Press the pairing key on speaker to wake it up.

Bluetooth pairing cannot be accomplished

A mobile phone has been paired with the speaker before, and such mobile phone is still within working range and the Bluetooth is not disabled, therefore when pairing again, the Bluetooth device will be automatically searched and connected. To solve the problem, disable the Bluetooth of previously connected Bluetooth device, the next Bluetooth device can then be searched and paired normally.

Bluetooth play sound is low

1. When mobile phone is connected with Bluetooth device, the volume of Bluetooth device is not turned up but at default level output; turn up the output volume of mobile phone.
2. The output volume of Bluetooth device is low.
3. The music itself sound is very small.

It doesn't have sound after Bluetooth connection

When Bluetooth device is connected with mobile phone, the audio of Bluetooth device is not opened, open the output volume of mobile phone.

Bluetooth plays normally but with interrupted sound

1. There is a block between mobile phone and Bluetooth device. Move away the block.
2. The distance between Bluetooth device and mobile phone exceeds the connection range. Shorten the distance between Bluetooth device and mobile phone.

Small voice of handsfree call answering after connecting Bluetooth for play

1. The volume of the Bluetooth machine is not turned up with the defaulted level output, turn up the volume.
2. The output volume of the mobile phone is small, turn up the volume.

Bluetooth cannot connect other mobile phone and devices

The Bluetooth device has connected the current mobile phone. To pair the other mobile phone, press and hold the pairing key on device to disconnect the previous mobile phone, wait until the other mobile phone has searched the name of paired Bluetooth and then click it for connection.

Cannot boot

Since the 3.7 V lithium battery inside the machine from the power phenomenon exists, it is recommended that you give the machine for 6 to 8 hours to fully charge before using the machine, and to ensure at least once a month charge re-use!

There is noise when the machine play

When an external charging, charging when the bad environmental conditions, may interfere with normal playback.

Failure of the machine function button when the phone is a music player

Please use the phone comes with the players. Some mobile phones software is not compatible, change the player software.



FCC Statement

FCC ID: 2ADJR-XBS958

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

Caution:

1. Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
2. The product shall only be connected to a USB interface of version USB2.0
3. Use the product in the environment with the temperature between -10°C and 40°C,

Hereby, Shenzhen Xrinda Technology Ltd. hereby declares that this Bluetooth Speaker, XBS958 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.