


QuickStart Setup Guide for the SimplicitySlate (SE-200)

Check The Contents



How to Use

There are a few different ways that you can connect the SimplicitySlate to your computer.

1) USB Dongle (Wireless)



Connect the USB dongle to your computer, and press the power button on the slate.

2) USB Cable (Wired)



Using the included micro USB to USB cable, connect one end to your computer, and the other end to the slate. Then press the power button on the slate.

3) Bluetooth® (Wireless)

For instructions on how to connect the slate using bluetooth, please visit:

www.recordexusa.com/se-200/bluetooth


Note: The slate has a built-in battery that can be charged via the USB cable. The Pen is completely passive, and does not require any batteries.

Your SimplicitySlate comes bundled with our XPress annotation software.

To download and install the most up to date version of our XPress software, go to: recordexusa.com/xpress

You'll find Windows®, macOS®, and Chrome OS™ versions of XPress, as well as, videos and guides to teach you how to use XPress.

- 1) Micro USB Connector
- 2) Power Button
- 3) Power Indicator LED
- 4) Bluetooth/Wireless Dongle Indicator LED
- 5) Charging/Battery LED
- 6) Active Writing Surface



1-Year Warranty

LIMITED 1-YEAR WARRANTY RECORDEX USA SimplicitySlate ("Product")

What is my warranty? Recordex warrants to the original purchaser ("You"/"Your") only that the Product will be free from defects in material and workmanship under normal use for a period of one (1) year from the date of original purchase* (see note below).

How long does this warranty last? One (1) year from the date of the original purchase*.

What is the typical warranty process? A service technician will attempt to resolve the problem by phone and or email. If the problem appears to require new hardware then:

The defective product will be replaced with a new or refurbished product at Recordex expense.

Who is responsible for Shipping? Recordex is responsible for picking up defective product from your school or business. Shipping expenses are only covered under warranty to the 48 contiguous United States. You are responsible for shipping, if necessary, to Alaska, Hawaii and any address outside of the United States. If the Product is repaired out of warranty then you are responsible for shipping both ways. Recordex has option to field abandon product and may instruct you to responsibly dispose of the defective product.

What must I do to obtain warranty service? To obtain warranty service please contact Recordex's Customer Service Center at 888-715-0278 and support@recordexusa.com or contact your authorized Recordex Integrator/Installer for assistance in filing a warranty claim. You will receive instructions on how to properly return your product for authorized warranty repair. In order to receive warranty service you must be able to provide an original receipt or invoice for the purchase of your Product.

What are the limitations? Recordex's warranty shall not apply: (i) to any Product subjected to accident, misuse, neglect, alteration, acts of God, improper handling, improper transport, improper storage, improper use or application, improper installation, industrial or commercial use, improper testing or unauthorized repair; or (ii) to cosmetic problems or defects that result from normal wear and tear under ordinary use, and do not affect the performance or use of the product. If the Product develops a covered defect within the warranty period, Recordex will, at its option, either repair or replace the Product at no charge, provided that the Product is returned during the warranty period and this is your exclusive remedy and the entire liability of Recordex under this warranty. No warranty is made or implied as to the effectiveness or suitability of this product for your purposes.

THE ABOVE STATED WARRANTY IS EXCLUSIVE AND REPLACES ALL OTHER WARRANTIES EXPRESSED OR IMPLIED INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. RECORDEX WILL NOT BE HELD LIABLE FOR ANY OTHER DAMAGES OR LOSS INCLUDING INCIDENTAL OR CONSEQUENTIAL DAMAGES AND LOSS OF PROFITS OR REVENUES FROM WHATEVER CAUSE, INCLUDING BREACH OF WARRANTY OR NEGLIGENCE.

*If the product is installed by an authorized Recordex Integrator/Installer the warranty period starts on the date the installation of the product is approved by authorized party. (I.e. Authorized Recordex Integrator/Installer installs product and authorized School District personnel signs-off on installation.)

Tech Support & Service

Go to www.recordexusa.com/support for links to manuals, frequently asked questions, and support.

Software Download and Training

Go to www.recordexusa.com/xpress to download our XPress Annotation Software.

For XPress training material, go to www.recordexusa.com/courses/xpress/

XPress

recordex™

FCC regulatory conformance:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF Exposure

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.