



Band4-1312-5-10000~18000MHz




Band4-1312-5-3000~10000MHz




Band4-1312-5-0.009~0.15MHz




Band4-1312-5-30~1000MHz



Band4-1312-5-0.15~30MHz




Band4-1413-1-0.15~30MHz




Band4-1413-1-0.009~0.15MHz



Band4-1413-1-30~1000MHz



Band4-1413-1-1000~3000MHz



Band4-1413-1-3000~10000MHz



Band4-1413-1-10000~18000MHz




Band4-1413-2-1000~3000MHz




Band4-1413-2-3000~10000MHz



Band4-1413-2-30~1000MHz



Band4-1413-2-0.15~30MHz




Band4-1413-2-0.009~0.15MHz




Band4-1413-2-10000~18000MHz



Band4-1413-3-30~1000MHz



Band4-1413-3-0.009~0.15MHz



Band4-1413-3-1000~3000MHz




Band4-1413-3-3000~10000MHz




Band4-1413-3-10000~18000MHz



Band4-1413-3-0.15~30MHz



Band4-1413-4-0.15~30MHz




Band4-1413-4-10000~18000MHz



Band4-1413-4-3000~10000MHz




Band4-1413-4-30~1000MHz



Band4-1413-4-0.009~0.15MHz




Band4-1413-4-1000~3000MHz




Band4-1413-5-10000~18000MHz




Band4-1413-5-0.15~30MHz



Band4-1413-5-30~1000MHz



Band4-1413-5-1000~3000MHz




Band4-1413-5-3000~10000MHz




Band4-1413-5-0.009~0.15MHz




Band4-1513-1-0.009~0.15MHz




Band4-1513-1-0.15~30MHz



Band4-1513-1-30~1000MHz



Band4-1513-1-1000~3000MHz



Band4-1513-1-3000~10000MHz