


Bluetooth Wrap Earbuds

User Manual

Product Overview



FCC ID: 2ADM5-EP-0176

Power on/off

Power on
Switch On/Off Button to left. The wireless headphones will vibrate and the LED indicator light will turn blue.

Power off
Switch On/Off Button to right. The wireless headphones will vibrate and the LED indicator light will turn off.

Pairing Bluetooth device

1. Keep the distance between your wireless earbuds and mobile phone (or other devices) within 32.8 Feet.
2. Power on the wireless headphones, then the LED indicator light will flash blue and red.
3. Activate the Bluetooth function on your phone within range and select "Infinite BTWrap" from the list shown.
4. The wireless headphones will vibrate when paired successfully.

Answering a call

When there is an incoming call, the wireless headphones will ring and vibrate, press the call button to answer the incoming call or answer the call via your mobile phone.

Ending a call

Press the call button once to end the call or hang up via your mobile phone.

Rejecting a call

Press the call button for 2 seconds when the wireless headphones rings.

Redialing a call

Double press the call button for redialing the last number that you just called.

Volume control

Volume up button
Long press: Increase volume
Short press: Play next track

Volume down button
Long press: Decrease volume
Short press: Play previous track

Charging product

While charging the wireless headphones, the LED indicator light will turn red. When the wireless headphones are fully charged, the LED indicator light will turn off.

Specification

Driver Diameter: 10mm
Impedance: 32 Ohms
Sensitivity: 105dB +/- 3dB
Frequency Response: 20Hz - 20kHz
Battery Capacity: 170 MAH
Battery Type: Li-Ion Battery 3.7V
Playing time: 2-2.5 hours
Bluetooth Range: 32.8 Feet
Bluetooth Version: 4.2(BR/EDR)

FAQ

1. If the wireless headphones cannot be paired with your device, please try the following:

Ensure that your wireless headphones are in pairing mode or reconnection mode. Ensure that Bluetooth search function of your mobile device is activated.

2. If the wireless headphones will not turn on:

Make sure the wireless headphones are fully charged.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure

limits set forth for a uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter