






Size: 297(W) x 105(H)mm

FRONT SIDE

  <h1 data-bbox="158 393 553 463">EVOLVE</h1> <p data-bbox="158 479 553 504">TRUE WIRELESS EARBUDS</p> <h2 data-bbox="158 512 553 544">INSTRUCTION MANUAL</h2> <p data-bbox="137 558 587 614">Thank you for purchasing the Evolve True Wireless Earbuds. This manual provides more information about the wireless earbuds, please read the instructions before using.</p> 	<h3 data-bbox="667 282 813 298">Product Overview</h3> <div data-bbox="667 314 1184 709">  </div> <h3 data-bbox="667 733 813 749">Package Contents</h3> <ul data-bbox="667 772 869 828" style="list-style-type: none"> 1(One) Pair Earbuds 1(One) USB-Type C Charging Cable 1(One) Portable Charging Case 1(One) Instruction Manual <h3 data-bbox="667 844 789 858">Specifications</h3> <p data-bbox="667 883 948 1034">Driver Diameter: 10 mm Impedance: 32 Ohms Frequency Response: 20 Hz - 20 kHz Sensitivity: 98 dB +/- 3 dB Power Supply: Li-ion Battery 3.7V 35 mAh Per Earbuds Total Playtime: 10 Hours Charging Time: <2.5 Hours Bluetooth Range: 32 Feet Bluetooth Version: 5.3 Charging Case Battery Capacity: 200 mAh USB Type-C Charging Cable Included USB Type-C Charging Cable Rating 5V/1A Max.</p>	<h3 data-bbox="1230 282 1343 298">Power On/Off</h3> <p data-bbox="1230 330 1704 376">Power On Touch and hold the Touch control area of earbuds for 3 seconds and the LED will flash.</p> <p data-bbox="1230 385 1704 433">Power Off Touch and hold the Touch control area of earbuds for 5 seconds and the LED will be off.</p> <h3 data-bbox="1230 463 1625 479">Pair the wireless earbuds with your mobile device</h3> <ol data-bbox="1230 512 1750 639" style="list-style-type: none"> Keep the distance between the earbuds and mobile device within 32.8 feet. De-activate the Bluetooth function on your mobile device. Put the earbuds back to charging case before use. Take both earbuds out from charging case and wait for 3 to 5 seconds for auto pairing. The earbud has indicator blinking. Another earbud will stop blinking when auto pairing is done successfully. Activate the Bluetooth function on your mobile device and select "EP-0736 TWS" from the list shown. After pairing is successful, both earbuds LED will stop blinking. <p data-bbox="1230 685 1738 717">*Attention: If the auto pairing is not successful, manual pairing between earbuds is essential by following below procedures:</p> <ol data-bbox="1230 725 1738 874" style="list-style-type: none"> Make sure the earbuds are charged. De-activate the Bluetooth function on your mobile device. (If you had been paired the earbuds to some other mobile device(s) nearby, please sure to de-activate those device(s) too). Power on both earbuds simultaneously by pressing the touch control area for 3 seconds and wait for 3 to 5 seconds for auto pairing. (Keep the Bluetooth function off on your mobile device before this operation.) Activate the Bluetooth function on your mobile device and select "EP-0736 TWS" from the list shown. After pairing successfully, both earbuds LED will stop blinking. <h3 data-bbox="1230 915 1659 931">Reconnect the wireless earbuds to your mobile device</h3> <p data-bbox="1230 953 1716 985">When powered on, the wireless earbuds will automatically connect with the last successfully paired device.</p>	<h3 data-bbox="1793 282 2234 298">Disconnect the wireless earbuds from your mobile device</h3> <p data-bbox="1793 322 2191 368">Power off the wireless earbuds; or Switch off the Bluetooth on your mobile phone; or Leave the earbuds 60ft away from your mobile phone or further.</p> <h3 data-bbox="1793 393 1964 409">Answer / Reject a call</h3> <p data-bbox="1793 433 2326 479">When receive a call, press the touch control area once (on either earbud) to accept the call, or answer the call normally via your mobile phone. Press and hold 2 seconds to reject it.</p> <h3 data-bbox="1793 504 1885 520">End a call</h3> <p data-bbox="1793 544 2326 574">To end the call, just press touch control area at any side of earbud with Beep sound to end it.</p> <h3 data-bbox="1793 598 1885 614">Functions</h3> <p data-bbox="1793 639 2191 701">Pause / Play Music: Short Press on touch control area Go back to previous song: Double click left touch control area . Advance to next song: Double click right touch control area . Voice Assistant: Press and hold touch control area for 2 seconds.</p> <h3 data-bbox="1793 733 1986 749">Charging your Earbuds</h3> <ol data-bbox="1793 772 2212 850" style="list-style-type: none"> Open the charging case cover. Insert the Earbuds into the charging case. The earbuds will start the charge automatically. LED indicator light of the Earbuds will be turned on when charging. Once fully charged, the LED will be off. <p data-bbox="1793 866 2268 899">Note: If the charging is not start, take out both earbuds from the charging case and insert again after few seconds.</p>
--	---	---	---

BACK SIDE

<p>Recharge Charging Case</p> <p>⚠ For your safety, please always use appropriate 5V output charger/Adapter to charge the product. DO NOT USE Quick Charging USB Adapter to charge the product, as it might damage the product.</p> <ol style="list-style-type: none"> 1. Use the USB Type-C charging cable provided with the packaging. 2. Connect the USB plug to a USB port on a wall adapter, then connect the USB Type-C plug to the USB Type-C charging port on the charging case to begin charging 3. The charging case's LED Indicator will be flashing during charging. 4. Once fully charged, the charging case's LED Indicator will stop flashing. 5. The Earbuds Battery Charging Indicator will be flashing during the earbuds are charging and will be off after fully charged. <p>NOTE:</p> <ul style="list-style-type: none"> • You must select a qualified charger from a regular manufacturer. • You must charge the charging case and earbuds if it has been not used for more than 6 months.  <p>USB Plug USB Type-C Plug</p> <div> <p>⚠ CAUTION: The USB Type-C charging cable included with this item is intended for use with this product. Only use the included USB Type-C charging cable to charge this product.</p> </div>	<p>FAQ</p> <p>If the wireless earbuds cannot be paired with your device, please try the following: Ensure that your earbuds are in pairing mode or reconnection mode Ensure that Bluetooth search function of your mobile device is activated.</p> <p>If the wireless earbuds will not turn on: Make sure the earbuds are fully charged. Make sure the protective stickers are removed from the Earbuds</p> <p>Can I change the battery for the earbuds and the charging case? The wireless earbuds and the charging case use a built-in non-detachable battery which cannot be removed.</p> <p>If the charging case cannot be recharged: If you use a power outlet, ensure that the power supply is connected securely and the outlet works.</p>	<p>⚠ Safety instructions for the lithium battery and charging the product</p> <ul style="list-style-type: none"> -The input voltage to the product is 5V 1A. -In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/ adapter for charging the product. -Only charge the product at ambient temperatures between 10 °C/ 50 °F and 40 °C/104 °F. -Do not heat above 70 °C/158 °F, eg. Do not expose to sunlight or throw into fire. -Switch off the product after use. -Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product. -In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development. 	<p>FCC Statement</p> <p>This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or experienced radio/ TV technician for help. <p>RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> <p>The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by 1616 Holdings, Inc. is under license. Other trademarks and trade names are those of their respective owners.</p> <p>FC</p> <p>FCC ID: 2ADM5-EP-0736</p> <p>Item# EP-0736 Distributed by 1616 Holdings, Inc. 701 Market Street, Suite 200 Philadelphia, PA 19106 Made in China</p> <p>Keep all relevant information for future reference</p>
---	--	--	---