

Remote-controlled amphibious double-sided vehicle 27MHZ

Working principle description

HD-4T128D: transmission is composed of TX66 coded IC and peripheral oscillation modulation and amplification circuit. When pressing the function key, the code is encoded by IC into a binary serial code, and the coded signal is loaded into the carrier by the modulation circuit, amplified by the amplifier circuit and transmitted out by the antenna.