




















Size: 13.7(W) x 8.66(H)in
350(W) x 220(H)mm

AGES 8+ MORPH-X REMOTE CONTROL TRANSFORMING JET Instruction Manual Thank you for purchasing the Morph-X Remote Control Transforming Jet. This manual provides more information about this product, please read the instructions before using. 	Product Overview  Morph-X Remote Control Transforming Jet  Remote Control  Instruction Manual	Package Contents 1(One) Morph-X Remote Control Transforming Jet 7.4in. X 4.33in. X 2.67in. (18.8cm X 11cm X 6.8cm) 1(One) Remote Control 10.15in. x 3.54in. x 1.41in. (25.8cm x 9cm x 3.6cm) 1(One) Instruction Manual Specifications Power Supply: Morph-X Remote Control Transforming Jet Power Supply: 3 x AAA 1.5V Batteries (Not Included) Remote Control Power Supply: 2 x AA 1.5V Batteries (Not Included) Frequency: 27 MHz (BLUE JET) 40 MHz (GRAY JET)	Operate Your Jet Note: To avoid losing control, always pay attention when playing the Morph-X Remote Control Transforming Jet. Forward  Press the forward button to control the Jet move forward Backward  Press the back button to control the Jet move backward (With Angle)	Operate Your Jet Robot Mode Transform  Press and hold the Robot Mode Transform button to control the Jet transform to Robot Mode Jet Mode Transform  Press and hold the Jet Mode Transform button to control the Jet transform to Jet Mode		
	Jet Power On/Off  Slide the ON/OFF Switch to ON to turn on, Slide the ON/OFF Switch to OFF to turn off.	Remote Control  Forward Button Robot Mode Transform Button Backward (With Angle) Button Jet Mode Transform Button	Batteries Installation-Jet  To install batteries into the Morph-X Remote Control Transforming Jet, unscrew the screw on the battery box cover to open the battery compartment. Insert 3 x "AAA" 1.5V batteries (Not Included) into the battery box. Batteries should be placed as shown on the diagram. Put back in place the battery box cover and tighten the screw. Notice: When placing the batteries, you must insert according to the correct polarity, the Morph-X Remote Control Transforming Jet won't function if batteries are reversed.	Batteries Installation-Remote Control  To install batteries into the Remote Control, unscrew the screw on the battery box cover to open the battery compartment. Insert 2 x "AA" 1.5V batteries (Not Included) into the battery box. Batteries should be placed as shown on the diagram. Put back in place the battery box cover and tighten the screw. Notice: When placing the batteries, you must insert according to the correct polarity, the Remote Control won't function if batteries are reversed.	Performance Tips 1. Do not drive the Morph-X Remote Control Transforming Jet in the sea or lake. 2. Do not drive the Morph-X Remote Control Transforming Jet in windy or rainy weather. 3. Do not drive the Morph-X Remote Control Transforming Jet into any sharp object. Care and Maintenance 1. Always use dry and soft cloth to clean this product. 2. Avoid this product from being exposed to sunlight or heat. 3. Avoid to immerse this toy into the water with the cover unlocked, otherwise, the electronic parts may be damaged. 4. Check the product regularly. If any damages are discovered, please stop using immediately, until it is completely repaired in good working condition. IMPORTANT: BATTERY INFORMATION For AAA Batteries ⚠WARNING: TO AVOID BATTERY LEAKAGE 1) The batteries used with this product are small parts and should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone American Association of Poison Control Centers (1-800-222-1222). 2) Always purchase the correct size and grade of battery most suitable for intended use. 3) Do not mix old and new batteries, alkaline, standard (Carbon - Zinc) or rechargeable (Nickel-cadmium) batteries. 4) Clean the battery contacts and those of the device prior to battery installation. 5) Ensure the batteries are installed correctly with the regard to polarity (+ and -). 6) Always remove batteries if consumed or if product is to be left unused for a long time.	For AA Batteries ⚠WARNING: TO AVOID BATTERY LEAKAGE 1) Be sure to insert the batteries correctly, and always follow the toy/game and battery manufacturers' instructions. 2) Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries. 3) Always remove weak or dead batteries from the product. 4) Remove the battery if the product is left unused for a long period of time. Warning This product is suitable to be used by people who has operating experience in remote toy or aged no less than 8 years old. Please do not put the product in your mouth to prevent choking hazard of small parts. Please do not put the finger into available interspaces. Please do not play the product in a brutal way such as throwing, crashing or twisting it. Please store the smaller-sized product accessories in places that are out of reach of children, in order to avoid the occurrence of accidents. Avoid placing the batteries in places in high temperatures and avoid exposure to heat. When young children are operating the product, it shall be ensured that the adults are guiding and making sure the product control is within the viewing range of the controller (or instructor) so that it makes the control of the toy more convenient. When the product is not in use, please switch off the power supplies of the toy, and remove the batteries from the product. Please note that we won't take any responsibility for any wrong operation as this may result in severe injury or loss of property, and we cannot control the operating process during the time when the user assembles or uses this product. Once this product is sold, we won't be responsible for any safety responsibility during the time the user operates or uses controls this products.