


12JUN25

底面印刷



REMOTE CONTROL INFLATABLE JACK SKELLINGTON Instruction Manual Thank you for purchasing the Remote Control Inflatable Jack Skellington. This manual provides more information about this product, please read the instructions before using. ©Disney www.disney.com	Product Overview Remote Control Inflatable Jack Skellington Charging Cable Remote Control Instruction Manual	Package Contents Includes: 1(One) Remote Control Inflatable Jack Skellington 1(One) Remote Control 1(One) Charging Cable 1(One) Instruction Manual Specifications Frequency: 2.4 GHz FCC ID: 2ADM5-ET-0876V3LG Remote Control Inflatable Jack Skellington Power Supply: 2 x Built-In, Rechargeable 3.7v 1200mAh Li-ion Batteries.(Included) Battery Charging Time: 4 Hours Play Time: Up To 20 Minutes Charging Cable Included Remote Control Power Supply: 2 x AA 1.5V Batteries (Not Included) Remote Control	Standard Control Note: To avoid losing control, always pay attention when controlling the Remote Control Inflatable Jack Skellington. Forward Button Control Remote Control Inflatable Jack Skellington to move forward Backward Button Control Remote Control Inflatable Jack Skellington to move backward	Standard Control Left Button Control Remote Control Inflatable Jack Skellington to turn left Right Button Control Remote Control Inflatable Jack Skellington to turn right	Inflate / Deflate Control Inflate Button Control Remote Control Inflatable Jack Skellington to Inflate / Deflate Deflate Button (When Remote Control Inflatable Jack Skellington turn on, it will inflate automatically)
---	--	---	--	---	---

Power On/Off • Press & hold the ON/OFF button 2 second to turn on • Press & hold the ON/OFF button 2 second to turn off	Remote Control Jack Skellington Battery Charging • Make sure switch off the Remote Control Inflatable Jack Skellington before charging. • Unscrew the screw on the battery box cover to open the cover. • Unplug and take out the rechargeable li-ion battery. • Connect the Rechargeable Li-ion Battery to the charging cable and plug on a USB power adapter for charging. • The LED indicator on the charging cable will turn red while charging and will turn green once fully charged. ⚠ For your safety, please always use appropriate 5V output charger/Adapter to charge the product. DO NOT Use Quick Charging USB Adapter to charge the product, as it might damage the product. NOTE: • You must select a qualified charger from a regular manufacturer.	Battery Installation For Remote Control Jack Skellington • To install battery into the Remote Control Inflatable Jack Skellington, unscrew the screw on the battery box cover to open the cover. • Connect the rechargeable li-ion battery to the Remote Control Inflatable Jack Skellington. • Insert the rechargeable li-ion battery into the battery box. • Replace the battery box cover and tighten the screw. NOTE: • Always ensure you charge the battery at least 4 hours before using to ensure maximum runtime.	IMPORTANT: BATTERY INFORMATION ⚠ WARNING: DROWNING HAZARD This is not a life-saving Device. Do not use in water. ⚠ Li-ion battery charging warning statement The input to the product is 5V 2A. In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/ adapter for charging the product. Only charge the product at ambient temperatures between 10 °C/ 50 °F and 40 °C/104 °F. Do not heat above 70 °C/158 °F, eg. Do not expose to sunlight or throw into fire. Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product. For AA Batteries ⚠ WARNING: TO AVOID BATTERY LEAKAGE 1) Be sure to insert the batteries correctly, and always follow the toy/game and battery manufacturers' instructions. 2) Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries. 3) Always remove weak or dead batteries from the product. 4) Remove the battery if the product is left unused for a long period of time. Charging Cable Rating 5V/2A Max. ⚠ CAUTION:The charging cable included with this item is intended for use with this product. Only use the included charging cable to charge this product. ⚠ CAUTION:FULLY CHARGE BEFORE USE	Performance Tips 1. Do not drive the Remote Control Inflatable Jack Skellington on grass, sand or go through water. 2. Do not drive the Remote Control Inflatable Jack Skellington in windy or rainy weather. 3. Do not drive the Remote Control Inflatable Jack Skellington into any sharp object. 4. Keep fingers, hair and loose clothing away from Remote Control Inflatable Jack Skellington.	FCC Statement This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or experienced radio/ TV technician for help. RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. FCC ID: 2ADM5-ET-0876V3LG FC Distributed by 1616 Holdings, Inc. 701 Market Street, Suite 200 Philadelphia, PA 19106 Made In Shantou, China Keep All Relevant Information for Future Reference Item# ET-0876-JACK
---	--	---	--	--	---