


Size: 322(w) x 100(h) mm

 Bluetooth® LED KARAOKE MICROPHONE Instruction Manual		Product Overview  Pair Wireless Microphone Speaker with your mobile device <ol style="list-style-type: none"> 1. Keep the distance between your wireless microphone speaker and mobile phone (or other devices) within 32.8 Feet. 2. Power on the wireless microphone speaker. 3. Activate the Bluetooth function on your phone within range and select "SP-1003-NBC" from the list shown. 4. You will hear a beep sound when pairing is successful. Reconnect Wireless Microphone Speaker to your mobile device <p>When powered on, the wireless karaoke microphone will automatically connect with the last successfully paired device.</p> Charging Your Wireless Microphone Speaker <p>⚠ For your safety, please always use appropriate 5V output charger/Adapter to charge the product. DO NOT USE Quick Charging USB Adapter to charge the product, as it might damage the product.</p> <ol style="list-style-type: none"> 1. Use the USB Type-C charging cable provided with this Wireless Microphone Speaker. 2. Connect the USB Type-C plug to USB Type-C charging port on the microphone, then connect the USB plug to a wall adapter to begin charging. 3. The LED Indicator will turn red while charging and will turn off once fully charged. <p>NOTE:</p> <ul style="list-style-type: none"> • You must select a qualified charger from a regular manufacturer. • You must charge the Wireless Microphone Speaker if it has been not used for more than 6 months. <p>USB Type-C Charging Cable rating 5V/1A Max.</p> <p>CAUTION: The USB Type-C charging cable included with this item is intended for use with this product. Only use the included USB Type-C charging cable to charge this product.</p> Power On/Off <p>Power on Press and hold the Power Button.</p> <p>Power off Press and hold the Power Button.</p> <p>Note: Always power off the karaoke microphone when not in use.</p> Technical Specification <table> <tbody> <tr> <td>Driver Diameter : 52 mm</td> <td>Power Supply : Li-Ion Battery 3.7V 600 mAh</td> </tr> <tr> <td>Impedance : 4 Ohms</td> <td>Bluetooth Range : 32.8 feet</td> </tr> <tr> <td>Playing Time : 2.5 - 3 Hours</td> <td>Bluetooth Version : 5.3</td> </tr> <tr> <td>Charging Time : 2 - 2.5 Hours</td> <td>USB Type-C Charging Cable Included</td> </tr> </tbody> </table>						Driver Diameter : 52 mm	Power Supply : Li-Ion Battery 3.7V 600 mAh	Impedance : 4 Ohms	Bluetooth Range : 32.8 feet	Playing Time : 2.5 - 3 Hours	Bluetooth Version : 5.3	Charging Time : 2 - 2.5 Hours	USB Type-C Charging Cable Included
Driver Diameter : 52 mm	Power Supply : Li-Ion Battery 3.7V 600 mAh														
Impedance : 4 Ohms	Bluetooth Range : 32.8 feet														
Playing Time : 2.5 - 3 Hours	Bluetooth Version : 5.3														
Charging Time : 2 - 2.5 Hours	USB Type-C Charging Cable Included														
 ©Disney www.disney.com		FCC FCC ID: 2ADM5-SP-1003V5 Distributed by 1616 Holdings, Inc. 701 Market Street, Suite 200 Philadelphia, PA 19106 Made in China	Keep All Relevant Information For Future Reference ITEM# SP-1003-NBC Date: Approval:												