




USER MANUAL

ACEMILE® | THEATRE BOX™ | CBT612

FCC ID:2ADMO-CBT612A



www.acemile.net

Welcome to be an ACEMILE® THEATRE BOX™ audiophile.

BRAND

THEATRE BOX™ is a top notch wireless portable audio system that brings all around 3D audio enjoyment using the global leading Q3D Holophony™ technology.

ACEMILE® creatively built a 4.1 channel audio system into a palm's grip. With four 2-inch full range driver and one 3-inch active bass driver well-tuned by a dual core digital audio processing circuit, the THEATRE BOX can smartly render HiFi quality music, movie or video game audio effects in an extremely vivid way. Just make sure to play it in an indoor space with area between 15 and 120 square meters without major obstacles. For optimal enjoyment, please listen to the stereo 2~7 meters in front of it.

CAUTION

- Before use the THEATRE BOX™, please carefully read the manual. Strictly follow the steps instructed. And heed all warnings below.
- Do not use this device near water. Clean it only with dry and soft fabric.
- Do not use the device near any heat sources such as the radiator, the stove, or other devices that produce heat.
- Only use accessories provided or specified by the manufacturer.
- Unplug the device during the thunder storm or when you expect to leave it idle for a long period.
- Do not expose the devices to water dripping or splashing.
- Do not place the device near hazardous chemicals or flame.

FCC CAUTION

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to

- correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

SPECS

10.3in (260mm) * 3.3 in (85mm) * 4.3 in (110mm)
Four 2-inch full range drivers + one 3-inch active bass driver
Q3D Holophony
Built-in microphone
Frequency Range 20Hz-20KHz
Bluetooth V4.0 compliant, A2DP 1.2, HFP 1.6
Support any music format. Support transmission of Apt-X, SBC and AAC
3.5 mm stereo input
Power supply: Adaptor Input:100 ~ 240V 50/60Hz 1.5A max
Output: 15V3A DC




REAR PANEL




Power Button & LED Indicator Pairing Button DC In Aux In

CONTROL PANEL





TURN ON/OFF

Press the power button to turn ON or turn OFF the unit.




NFC


If your device is with NFC function, simply approach its NFC area with the  mark of the THEATRE BOX™.




TV AUDIO




PAIR

Note: If the Bluetooth connection is preoccupied, and you want to have a new device connected to the THEATRE BOX™, **hold the  button** until the LED flashes white and red indicating that it enters pairing mode.




CHARGE

Connect the THEATRE BOX™ with a power outlet using the power adaptor. The LED ring indicator will turn white when the device is fully charged. Fully charging from ground zero takes about 4.5 hours. Normally, a fully charged THEATRE BOX™ can playback for up to 20 hours. When the power is low, the LED ring indicator will turn red.



AUX IN



DECLARATION OF CONFORMITY

Hereby, ACEMILE® Inc declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.



CONFERENCE CALL

