

## **Introduction**

Thank you for choosing the BTS200 as your source for entertainment , you can use this item with iPads,iPhones, iPods and many types of smartphone to stream music , and enjoy handsfree calling.In order to get the best results when using the device,please read this manual first before using.


## **Important Waterproof/Safety Information**

Important: DO NOT submerge the BTS200 speaker in water, this unit is not intended to function properly after being under water.

BTS200 is rated IPX6, which means the speaker can be heavily splashed with water or left in the rain (but not submerged in water) for approximately a limited time. If the BTS200 gets wet, it is recommended that you dry the speaker completely before using it again.

Please note: Speaker is not water-resistant when the silicone cover is open. please make sure that cover is closed and secure before using in a wet environment.

## Description:



## Description:

- 1.ON/OFF button
- 2.Play/Pause/Phone
- 3.MIC
- 4.Previous/Volume –
- 5.Next/Volume +
- 6.Blue LED(Bluetooth)
- 7.Red LED(Charging)
- 8.Green LED(AUX)
- 9.Micro USB Charging Port
- 10.AUX in Port

## Included:

- 1.Speaker
- 2.USB Micro Charging Cable
- 3.3.5 mm Audio Cable
- 4.User Manual

## **Specifications**

Supported Profiles: A2DP, HFP, AVRCP

Bluetooth Range:33ft (10m)

Dimensions: 180 mm x 65 mm

Battery: Li-Ion 3.7V, 1000 mAh

Charging: 5V @ 500 mA

## **Operation**

### **Powering On**

Press and Hold "ON/OFF" button 2 seconds to power ON, the Blue LED will start to flash.

If an Aux (3.5 mm) cable is connected to the unit, the Blue LED will turn off, and the Green LED will stay illuminated, notifying you, the unit is in Aux-In mode. .

### **Powering Off**

Press and Hold "ON/OFF" button 2 seconds to power OFF

## **Bluetooth Mode**

### **Pairing**

The unit will automatically go into "Pairing Mode" when it is powered ON.

Go into your Bluetooth device settings menu and look for "BTS200".

After the unit has paired and connected, it will re-connect automatically when the unit is powered on and the device is in range.

Note: Bluetooth Timeout :10 minutes

## **Begin Streaming Music**

Press " " to start playing music

Press and Hold " " 2 seconds to play the next track

Press and Hold " " 2 seconds to play previous track

Press either " " or " " for volume control

## **Making and Receiving Phone Calls**

When the unit is connected and paired to your device, the unit allows you to make or receive phone calls with its built-in microphone.

Press " " to accept a call

To end a call press " "

To place a call, simply dial the number or select a contact from your Bluetooth device and call

To reject a call, press and hold " " for 2 seconds

### **Aux-In Mode**

Plug in the supplied 3.5 mm cable into the unit. The other end is connected to your device. The Green LED will only illuminate when in "Aux" mode.

Please note music and volume can be controlled by your device.

### **Charging**

Attach the USB cable to the unit, and plug into any USB charger. If the unit is completely discharged, it will take approximately 4 hours to fully charge.

The Red LED will illuminate during charging, when it has completed, the Red LED will turn off.

Note: There will be a beep when the battery is low and needs to be recharged

### **LED Status**

|                                      |  |
|--------------------------------------|--|
| Blue LED flashing & Green LED solid  | Bluetooth Mode   |
| Green LED on solid                   | Aux Mode, Charging Completed                           |
| Red LED                              | Charging   |
| <b>Trouble shooting</b>              |  |
| Unit doesn't connect to device       | Speaker needs to be connected/re-paired to device      |
| A tone is heard every few seconds    | Speaker needs to be charged                            |
| Unit will not power on               | Speaker needs to be charged                            |
| Unit doesn't control track(s)/volume | Speaker needs to be in Bluetooth mode for full control |
| Unit distorts at high volume         | The devices' volume needs to be lowered                |

## **FCC Caution.**

### **§ 15.19 Labelling requirements.**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **§ 15.21 Information to user.**

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **§ 15.105 Information to the user.**

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

\* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.