# JE JOUE

**BUTT PLUGS** 

Je Joue has designed three butt plugs, each varying in size, shape and weight.

Designed with pure pleasure in mind, these body-safe vibrating butt plugs is the luxury your butt deserves.

The powerfully low-frequency rumbling vibrations will penetrate your pleasure spots from deep within. With the sizes varying, there is truly something for everyone interested in unlocking the joys of anal play.

#### Lubrications

We recommend using only water-based lubricants with our toys.

## For cleaning:

We recommend washing your toy with warm water and soap.















## Instructions:

- To turn the toy on, hold the + button until the red light shows and it begins vibrating
- To increase the vibration speed, use the + button
  To decrease the vibration speed use the button
- To try out the various vibrations patterns, use the middle button
   To turn the toy off hold the button until the
- red light goes off and the toy stops vibrating.
   Remote control is bluetooth technology and will connect to the butt plug once turned on.
- To use the travel lock please hold down the + and - for approx 5 seconds when in off mode. To uplock do the same

- Remote control is not waterproof
  Once you have finished using your toy we
- recommend cleaning it with warm water and soap.

   After your toy has dried, store in a cool, dry
- place
- For all Je Joue products, use only water based lubricants
- Remember to keep your toy charged. It takes 1.5hrs to charge which allows 1 hour of play on the highest setting.

# **Limited Warranty:**

Je Joue warrants your toy for a period of one year from the date of original purchase against any defects due to faulty materials or workmanship. If the product fails during the warranty period, Je Joue will repair or replace it free of charge.

To obtain service under this warranty, return the defective product to the retailer from whom you purchased your toy, together with your sales receipt, address, and a daytime phone number.

This warranty does not cover defects caused by accidental damage, misuse or other use not in

accordance with this instructional manual and its safety warnings.

Removing the battery from your toy or otherwise dismantling or tampering with your toy invalidates the warranty and may prevent your toy from being repaired.

,
Je Joue is unable to accept returns or exchanges
of non-defective products after the seal on the
packaging has been broken.

This warranty does not affect your statutory rights as a consumer in any way.

Je Joue supports your toy purchased in the UK. If your toy was purchased from elsewhere then Je Joue may attempt a repair but cannot guarantee the outcome.

## Je Joue Toys

Safety Information -

#### IMPORTANT SAFETY INFORMATION

READ ALL INSTRUCTIONS BEFORE USE.
DO NOT DISCARD THESE INSTRUCTIONS.
WARNING! WHEN USING ELECTRICAL PRODUCTS
BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE
FOLLOWED.

To reduce the risk of electrocution, burns, fire.

- dangerous electric shock or injury:

  1. DO NOT place or store your toy or the charger in any liquid (other than water in accordance with these
- instructions).

  2. DO NOT use your toy whilst it is charging.
- 3. DO NOT charge your toy whilst it is in, or near to, water or any other liquid.
- 4. DO NOT use a power adapter other than the charger included with your toy or purchased from Je Joue. If you

need a replacement part, please contact us.

- DO NOT plug the charger into an incorrect voltage source outlet. For correct voltage specification refer to the wall plug label.
- 6. DO NOT use with voltage converters and plug adapters.
  7. DO NOT force the charger plug into an electrical outlet.
- NOI force the charger plug into an electrical ou
   NOI use the charger if the charger or its wire is
- damaged in any way.

  9. DO NOT attach your toy to the charger when wet or
- when your hands are wet.

  10. ALWAYS unplug your toy from the charger before cleaning (in accordance with these instructions).
- ALWAYS ensure that your toy is dry before connecting it to the charger and plugging the charger into an electrical
- outlet.
  12. ALWAYS connect the charger to a properly grounded
  - electrical outlet.

    13. DO NOT charge your toy outdoors.
  - 13. DO NOT charge your toy outdoors.

- 14. DO NOT operate or charge your toy where aerosol products are being used, or where oxygen is being administered.
- 15. Whilst your toy is water resistant and is capable of safe use both in the bath or shower, it should not be submerged for prolonged periods of time and should be dried completely after such use.
- DO NOT use your bullet in water of extreme temperature (hot or cold).
- To reduce the risk of electrocution, burns, fire, dangerous electric shock or injury:
- Use your toy only in accordance with these instruction manuals.
   DO NOT use your toy with accessories that are not
- recommended by Je Joue.

  3. DO NOT attempt to dismantle or otherwise tamper with your toy, its charger or any of its components. Doing so may result in injury and invalidate your warranty.

- 4. DO NOT use the charger if the main cord or power supply is damaged, or if your toy is not functioning properly.
  5. NEVER operate your toy if it or any of its components have been dropped, damaged, or are not working in any
- way (if you encounter any problems, please contact us and return the product for examination and repair).

  6. DO NOT dispose of your toy or any of its components.
- in a fire.
- Keep your toy and the charger cord away from heated surfaces.
   He charging connectors on your bullet are exposed.
  - 8. The charging connectors on your bullet are exposed and extra caution should therefore be taken when handling the product.
- 9. DO NOT use the adaptor/charger supplied with your toy with any other equipment.
   10. DO NOT use other adaptors/chargers other than those
- supplied with your toy. 11. The chargers may become hot during use – take care

when handling, allow heat to disperse.

To reduce the risk of electrocution, burns, fire,

danaerous electric shock or injury during operation: ALWAYS operate your toy in accordance with these

instructions. 2. Your toy is not a child's toy. Please keep away from

children 3. NEVER attempt to remove the fascia. 4. NEVER operate your bullet without a properly fitted and

undamaged silicone cover or fascia. 5. DO NOT operate your toy if the outer layer of silicone has been damaged.

6. DO NOT drop your toy. This could cause irreparable damage and may invalidate the warranty.

7. ALWAYS attach the charger to your toy, then to the outlet. To disconnect, turn the socket off, remove the plug from the outlet, and then disconnect the charger from your toy.

8. ALWAYS dispose of your toy, the charger and used 12. Your toy may get hot when charging, DO NOT COVER, batteries properly. Do not incinerate, Batteries may explade if overheated. Do not wrap them in metal or aluminium foil. Wrap them in a newspaper before discarding. Je Joue

recommends that you contact your local officials to determine proper battery disposal or redemption sites in your great 9. DO NOT disassemble, crush or puncture the battery, or allow metal objects to contact the battery terminals. 10. ALWAYS unplug the charger from the electrical outlet

when not in use. 11. DO NOT place your finger or any other part of your body between your toy and the charger while it is plugged into an electrical outlet

12. DO NOT at any time place your toy or the charger in a dishwasher 13. DO NOT operate your toy under a blanket or pillow or other protective layers to prevent the risk of excessive heating and possible fire, electric shock or injury to persons.

14. DO NOT leave your toy unattended on any surface while it is operating 15. DO NOT use your toy for any other purpose other

MEDICAL CONSIDERATIONS 1. Your bullet serves exclusively for body massage and

than is described in this safety manual.

intimate stimulation of erogenous zones. DO NOT use your toy for other uses. 2. CONSULT a doctor before using your toy if you have an implanted device, such as a pacemaker or if any surgical

3. It is important to note that pathogens could be transmitted between people by sharing your toy. To protect

against the risk of transmitting pathogens, do not share your toy with other people. 4. DO NOT use your toy if you encounter any discomfort

during or after use.

5. DO NOT use your toy as a substitute for medical attention 6. DO NOT massage your toy on a single area for more

than 15 minutes. 7. DO NOT massage your toy on any area of the body that is swollen, inflamed or erupted

8. DO NOT massage your toy on the abdomen if it is painful or if you are pregnant. 9. DO NOT use your bullet on unexplained calf pain. 10. DO NOT massage your toy on the upper neck grea

near the base of the skull. operations have been carried out on the relevant body parts, 11. AVOID your toy from having contact with the eye or eyelid. 12. DO NOT use your toy on sensitive skin areas or in the

presence of poor circulation. 13. This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given

supervision or instruction concerning use of your toy by a person responsible for their safety.

• Always clean your toy after use to reduce the risk of

Your toy is not intended as a medical appliance.

If you have concerns regarding your health, consult your doctor before using this product.

our doctor before using this product

infections

## **FCC** and IC Information

Model: Onyx, Vesta, Egon, JJR1
Product name: Massage Device & Remote
Caution: The user is cautioned that changes or
modifications not expressly approved by the party
responsible for compliance could void the user's
authority to operate the equipment.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s) and Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause interference.
(2) This device must accept any interference, including

interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

suivaines:

(1) L'appareil ne doit pas produire de brouillage;

(2) L'appareil doit accepter tout brouillage er radioélectrique subi, même si le brouillage est suscensible d'en compromettre le fonctionnement.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against

harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference or adio communications. However, and appropriate that interference will not occur in a particular installation.

particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to carrect the interference by one or

- more of the following measures:

   Recrient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit

different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

FCC & IC Radiation Exposure Statement:

This equipment complies with FCC and Canada radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Déclaration d'l'C sur l'exposition aux radiations:

aux radiations définies par le Canada pour des environnements non contrôlés. Cet émetteur ne doit pas être installé au même endroit ni utilisé ques une autre autres en un autre émetteur.