



Photograph of the depth in the Head Phantom (835MHz)



Photograph of the depth in the Body Phantom (835MHz)



Photograph of the depth in the Head Phantom (1900MHz)




Photograph of the depth in the Body Phantom (1900MHz)




Photograph of the depth in the Head Phantom (2450MHz)




Photograph of the depth in the Body Phantom (2450MHz)




**Right Head Tilt Setup Photo**



**Right Head Touch Setup Photo**



**Left Head Tilt Setup Photo**



**Left Head Touch Setup Photo**



**10mm Body-worn Rear Side Setup Photo**



**10mm Body-worn Front Side Setup Photo**



10mm Body-worn Top Side Setup Photo



10mm Body-worn Bottom Side Setup Photo



10mm Body-worn Left Side Setup Photo



10mm Body-worn Right Side Setup Photo