

# Wireless Keyboard

## Instructions

Model : KM-236W 180771

**Important: Read before use. • Importante: Leer antes de usar.**

**ENGLISH** : The frequency band used by this product is 2402 - 2480 MHz. The maximum emitted transmission power is 0.0123 mW E.I.R.P. This device complies with the requirements of CE RED 2014/53/EU. The Declaration of Conformity for is available at:  
**DEUTSCH** : Das verwendete Frequenzband dieses Produkts ist 2402 - 2480 MHz. Die maximal abgestrahlte Sendeleistung beträgt 0,0123 mW E.I.R.P. Dieses Gerät entspricht der CE RED 2014/53/EU. Die Konformitätserklärung für dieses Produkt finden Sie unter:  
**ESPAÑOL** : Este dispositivo cumple con los requerimientos de CE RED 2014/53/EU. La declaración de conformidad esta disponible en:  
**FRANÇAIS** : Cet appareil satisfait aux exigences de CE RED 2014/53/EU. La Déclaration de Conformité est disponible à :  
**POLSKI** : Urządzenie spełnia wymagania CE RED 2014/53/EU. Deklaracja zgodności dostępna jest na stronie internetowej producenta:  
**ITALIANO** : Questo dispositivo è conforme alla CE RED 2014/53/EU. La dichiarazione di conformità è disponibile al:



**Warning:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help
- NOTE:** This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

The device has been evaluated to meet general RF exposure requirement.

**ENGLISH**

**Connecting via 2.4 GHz Receiver:**

- 1 Insert the receiver
  - Remove the wireless receiver located under the mouse's battery cover
  - Plug the receiver into an available USB port on your computer.
- 2 Power the keyboard
  - Insert two AAA battery into the keyboard's battery compartment.
  - Press the 2.4G button to switch to 2.4G mode (the indicator light with turn red).
- 3 Power the mouse
  - Insert one AA battery into the mouse's battery compartment.
  - Press the switch button at the bottom of the mouse to switch to 2.4G mode (the indicator light with turn white).

[support.manhattanproducts.com/barcode/180771](https://support.manhattanproducts.com/barcode/180771)



**North & South America**  
IC Intracom Americas  
550 Commerce Blvd.  
Oldsmar, FL 34677, USA

**Asia & Africa**  
IC Intracom Asia  
4-F, No. 77, Sec. 1, Xintai 5th Rd.  
Xizhi Dist., New Taipei City 221, Taiwan

**Europe**  
IC Intracom Europe  
Löhbacher Str. 7  
D-58553 Halver, Germany

All trademarks and trade names are the property of their respective owners. © IC Intracom. All rights reserved. Manhattan is a trademark of IC Intracom, registered in the U.S. and other countries.



Printed on recycled paper.

## For additional benefits:

Scan to  
register your  
product warranty



or go to: [register.manhattanproducts.com/r/180771](https://register.manhattanproducts.com/r/180771)

**Keyboard function keys**

Function		Description
Fn +	F1	Mute
	F2	Volume Down
	F3	Volume Up
	F4	Previous Track
	F5	Play / Pause
	F6	Next Track
	F7	Brightness Down
	F8	Brightness Up
	F9	Select All
Fn +	F10	Copy
	F11	Paste
	F12	Cut
	Esc	Switch between Fn+ / single press
2.4G		Switch between devices
Win/Mac		Switch layout mode for OS