

Wireless Keyboard

Instructions

Model : KM-263W 180795

Important: Read before use. • Importante: Leer antes de usar.

REGULATORY STATEMENTS

ENGLISH : The frequency band used by this product is 2402 - 2480 MHz. The maximum emitted transmission power is 0.0123 mW E.I.R.P. This device complies with the requirements of CE RED 2014/53/EU. The Declaration of Conformity for is available at:
DEUTSCH : Das verwendete Frequenzband dieses Produkts ist 2402 - 2480 MHz. Die maximal abgestrahlte Sendeleistung beträgt 0,0123 mW E.I.R.P. Dieses Gerät entspricht der CE RED 2014/53/EU. Die Konformitätserklärung für dieses Produkt finden Sie unter:
ESPAÑOL : Este dispositivo cumple con los requerimientos de CE RED 2014/53/EU. La declaración de conformidad esta disponible en:
FRANÇAIS : Cet appareil satisfait aux exigences de CE RED 2014/53/EU. La Déclaration de Conformité est disponible à :
POLSKI : Urządzenie spełnia wymagania CE RED 2014/53/EU. Deklaracja zgodności dostępna jest na stronie internetowej producenta:
ITALIANO : Questo dispositivo è conforme alla CE RED 2014/53/EU. La dichiarazione di conformità è disponibile al:

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

--Increase the separation between the equipment and receiver

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter
The device has been evaluated to meet general RF exposure requirement.



support.manhattanproducts.com/barcode/180795



North & South America
IC Intracom Americas
550 Commerce Blvd.
Oldsmar, FL 34677, USA

Asia & Africa
IC Intracom Asia
4-F, No. 77, Sec. 1, Xintai 5th Rd.
Xizhi Dist., New Taipei City 221, Taiwan

Europe
IC Intracom Europe
Löhbach Str. 7
D-58553 Halver, Germany

All trademarks and trade names are the property of their respective owners. © IC Intracom. All rights reserved. Manhattan is a trademark of IC Intracom, registered in the U.S. and other countries.

For additional benefits:

Scan to register your product warranty



or go to: register.manhattanproducts.com/r/180795

ENGLISH

Connecting via 2.4 GHz Receiver:

1 Insert the receiver

- Remove the wireless receiver located under the mouse's battery cover
- Plug the receiver into an available USB port on your computer.

2 Power the keyboard

- Insert two AAA battery into the keyboard's battery compartment.
- Press the 2.4G button to switch to 2.4G mode (the indicator light with turn red).

3 Power the mouse

- Insert one AA battery into the mouse's battery compartment.
- Press the switch button at the bottom of the mouse to switch to 2.4G mode (the indicator light with turn white).

Keyboard function keys

Function	Description
Fn +	F1 Mute
	F2 Volume Down
	F3 Volume Up
	F4 Previous Track
	F5 Play / Pause
	F6 Next Track
	F7 Brightness Down
	F8 Brightness Up
	F9 Select All
Fn +	F10 Copy
	F11 Paste
	F12 Cut
	Esc Switch between Fn+ / single press
2.4G	Switch between devices
Win/Mac	Switch layout mode for OS

For specifications, please visit
manhattanproducts.com.