

# FashionFit

## WHAT'S INCLUDED

Your FashionFit includes:

- Watch module
- Silicon case with band
- Metal bangle
- Charger

## WHAT FASHIONFIT TRACKS

Your FashionFit tracks:

- Steps taken
- Calories burned
- Distance traveled
- Active time
- Time slept / deep sleep

## CHARGING YOUR FASHIONFIT

Your FashionFit must be charged before start using it. And you should charge your FashionFit when a flashing empty battery appear on the display. This flashing symbol is to let you know the battery power is down to 15% or below. To charge your FashionFit, please follow the steps below.

1. Remove your watch module from the metal bangle or silicon case.
2. Plug your charging cable into a USB port on your computer.
3. Insert your watch module into the charger as per the instruction attached to the charger.
4. Your watch module will show a charging symbol which is a battery with lightning sign. This symbol will disappear in a few seconds. You can bring it back by pressing the buttons on the side watch module.
5. Charge until the battery sign is filled up. It usually takes 3 to 4 hours to fully charge the battery. Your FashionFit will run for 3 to 4 days before next charging.

## HOW TO PUT ON YOUR FASHIONFIT

The watch module is interchangeable between the silicon case and the metal bangle. First, align the ridges on the side of the watch module with the notches on the back side of the silicon case or metal case. Then, plug the watch module into the silicon case or metal case.

## CARE AND WEARING TIPS

The following are tips when caring for your FashionFit:

- Clean and dry the FashionFit regularly, particularly under the band.
- Wear your FashionFit band loosely enough to allow air circulation.
- Use skin care products sparingly on the areas of the wrist covered by the FashionFit.

## SETTING THE TIME

You do not need to set the time manually. When synchronizing the data on your watch to the apps on your phone, the time of your phone will be synchronized to the watch.

## TURNING YOUR FASHIONFIT ON

Press and hold the button at 3:00 for 3 seconds. If the watch does not turn on after removal from the box, it will need to be charged before it is able to turn on.

## TURNING YOUR FASHIONFIT OFF

Press and hold button at 3:00 for 5 seconds.

## WATCH MODULE BUTTON OPERATION

- Press 3:00 button to display:
  - "ANNE KLEIN" logo
  - Time & date
  - Calorie burned

# FashionFit

- Steps taken
- Distance traveled
- Time sleep / deep sleep
- Press 9:00 button to show sleep mode:
  - If the sleep mode is off (it shows “Z OFF”), press 3:00 to start sleep monitoring.
  - If the sleep mode is on (it shows “Z ON”), press 3:00 to stop sleep monitoring. Then, it will show the monitoring result of the sleep.

## SETTING UP FASHIONFIT ON A MOBILE PHONE

1. Install the FashionFit app. (You can find the FashionFit app on the iOS App store or Google Play store by searching for “FashionFit”.) FashionFit runs on Android 4.3 and above, iOS 7 and above.
2. Turn on the Bluetooth on your mobile phone.
3. On the watch module, press 3:00 button until it shows “ANNE KLEIN” logo.
4. Press and hold the 9:00 button for a few seconds, it will show a validation code which is in 12 digits or letters.
5. Enter this validation code to the apps. (at setting section, in the tab “Device”)
6. Before you finish inputting the validation code, the display will blackout in 15 second. You can bring it back just by pressing the buttons.
7. After entering the validation code, tap “Pairing”.
8. Input the required info in the tab “Info”.
9. Set your goal by entering no. of step in tab “Goal”.
10. Then go to “Home” page and tap “Sync” to sync the fitness data and time.
11. You can also tap “Start” to activate real time monitoring your fitness data like steps, distance, etc. To stop the real time monitoring, tap “Stop”.

## OTHER FEATURES OF THE APPS

- When the daily goal is achieved, there will be a gold star tagged right at the date so you can see how much of your achievement.
- The apps provides weekly, monthly and yearly report. You can review your fitness data history easily.

## MEMORY

Your FashionFit holds the detailed data for the most recent 7 days. The recorded data consists of steps taken, calories burned, distance traveled, active time and sleep monitoring. Sync your FashionFit regularly to have the most detailed data available to view on your mobile phone installed with FashionFit apps.

## REGULATORY NOTICE

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

# FashionFit

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## IMPORTANT SAFETY INSTRUCTIONS

While your FashionFit is designed to be worn 24/7, its components are electronic and susceptible to damage if used improperly. Please read the safety guidelines on the following to ensure proper use and care.

- Read these instructions.
- Keep these instructions.
- Heed all warnings
- Follow all instructions
- Do not attempt to open the module case. Substances contained in this product and/or its battery may damage the environment and/or human health if handled and disposed of improperly.
- Do not tamper with or abuse your FashionFit.
- Do not use abrasive cleaners to clean your FashionFit.
- Do not place your FashionFit in a Dishwasher, Washing Machine or Dryer.
- Do not expose your FashionFit to extremely high or low temperatures.
- Do not use your FashionFit in a sauna or steam room.
- Do not leave your FashionFit in direct sunlight for an extended period of time.
- Do not leave your FashionFit near open flames.
- Do not dispose of your FashionFit in a fire. The battery could explode.
- Do not attempt to disassemble your FashionFit, it does not contain serviceable components.
- Never allow children to play with the FashionFit; the small components may be a choking hazard!

## BUILT-IN BATTERY PRECAUTIONS

- Do not attempt to replace your FashionFit battery. It is built-in and not changeable.
- Charge the battery in accordance with the instructions supplied with this guide.
- Use only the charger that shipped with your product to charge the battery.
- Charge your FashionFit using a certified computer, powered hub or power supply.
- Do not attempt to force open the built-in battery.
- Do not expose your FashionFit to liquid, moisture, humidity, or rain while charging. Exposure of the FashionFit to moisture while charging could result in electric shock.
- Do not charge your FashionFit in extremely high or low temperatures.
- Do not clean your FashionFit when it is being charged. Always unplug the charger first before cleaning your FashionFit.

## DISPOSAL AND RECYCLING

Please kindly be aware that it is the consumer's responsibility to properly dispose and recycle FashionFit and accompanying components. Do not dispose of FashionFit with common household waste, the FashionFit unit is considered electronic waste and should be disposed of at your local electronic equipment collection facility.

For more information, please contact your local electronic equipment waste management authority or the retailer where you bought the product.

## HEALTH DISCLAIMER

**WARNING: FASHIONFIT IS NOT A MEDICAL DEVICE.** The FashionFit should not be used to diagnose, treat, or prevent any disease or medical condition. Always seek the advice of a qualified medical professional before making any changes to your exercise, sleep or nutrition, as doing so may cause severe harm or death.