





WM_ONN
Cannice
100130685
onn. open ear earphones gen 2
OPT01_QSG
06/14/2023


<div><div><div>onn</div><div>USER GUIDE</div><div>Wireless Open-Ear Earphones</div></div><div></div><div>AABLUI00130685-EN-04232025</div></div>		<div>Contents & Information</div> <div><div>CONTENTS & INFORMATION</div><div>Features</div><div>OVERVIEW</div><div>SAFETY PRECAUTIONS</div><div>OPERATION</div><div>First time setup</div><div>Power on & Power off</div><div>Pairing</div><div>Play music</div><div>Phone calls</div><div>Charging</div><div>CLEANING & CARE</div><div>SPECIFICATIONS</div><div>TROUBLESHOOTING</div></div> <div>1</div>	<div>Features</div> <div>1. Speaker Diameter: 14.2mm</div> <div>2. Multi-point Connections</div> <div>3. Adjustable multi-angle open-ear design</div> <div>4. Dual built-in microphones with environmental noise cancellation in each earphone</div> <div>5. Up to 7+ hours of playtime per charge</div> <div>6. 24 hours of total playtime (with charging case)</div> <div>7. Bluetooth range: 10m/32.8ft</div> <div>8. IPX5 water-resistant* (applies to the earphones, not to the charging case)</div> <div>2</div>	<div>Overview</div> <div><div><div>CHARGING CASE</div><div>CHARGING PORT</div><div>PAIRING BUTTON</div><div>LED INDICATOR</div></div><div><div>CHARGING CABLE</div><div>EARPHONE</div><div>Mic2</div><div>Mic1</div><div>Ear Hook</div><div>Multi-angle Arm</div><div>Touch Control Area</div></div></div> <div><div>LED INDICATOR</div><div>Green : battery > 50%</div><div>Orange : battery 21%-50%</div><div>Red : battery ≤ 20%</div></div> <div>3</div>	<div>Safety Precautions</div> <div><div>FCC Statement</div><div>Consult the dealer or an experienced radio/TV technician for help.</div><div>FCC RF exposure statement.</div><div>Warning:</div><div>Ver:05 04/23/25</div><div>5</div></div>	<div><div>onn</div><div>For product assistance WE CAN HELP</div><div>1-888-516-2630</div><div>7 DAYS/WEEK</div><div>7:00am- 9:00pm CST</div><div>Find more at Walmart.com</div><div>Manufactured in India for: Walmart, Inc.</div></div> <div><div>THIS GUIDE CONTAINS IMPORTANT SAFETY INFORMATION.</div><div>PLEASE READ AND KEEP FOR FUTURE REFERENCE.</div></div> <div>6</div>
--	--	---	--	---	--	--

Operation

FIRST TIME SETUP

Device may need to be charged before use.





1. Remove the protective films before the first use, then place both earphones back into charging case and close the lid.

2. When you open the lid again, earphones will enter into pairing mode automatically.


3. Find "onn TWS Open-Ear Pro" in device Bluetooth settings.

7

POWER ON & POWER OFF

POWER ON

Open the charging case, earphones will power on and connect to last paired device automatically.



POWER OFF

Place earphones back to charging case and close the lid, earphones will power off automatically.

Note: Without the charge case, you can also power on or power off the earphones by touching and holding the earphone button for 4-6 seconds.


PAIRING

HOW TO PAIR WITH ANOTHER DEVICE

8

A. When earphones are connected to your current device, disable Bluetooth on your current device, earphones will enter pairing mode immediately.

B. When earphones are NOT connected to your current device, place both earphones back to charging case, hold the pairing button for 2 seconds, now you can search it from another device.



HOW TO PAIR WITH 2 DEVICES SIMULTANEOUSLY (MULTIPOINT CONNECT)

1. When a device is connected to the earphones, place both earphones back into charging case.

2. Keep the lid open meanwhile press and hold the pairing button for 2 seconds, now you can search it from your second device and connect it, then both devices are connected to the earphones.

9

PLAY MUSIC

Control	Action	Result
	x 2 Tap (Either one)	Play / Pause
	x 3 Tap (Either one)	Voice assistant
	Hold 2 seconds (Right one)	Next track
	Hold 2 seconds (Left one)	Previous track

PHONE CALLS


Control	Action	Result
	x 2 Tap (Either one)	Answer incoming call
	x 2 Tap (Either one)	End current call
	Hold 2 seconds (Either one)	Reject incoming call

10

CHARGING

CHARGE EARPHONES


Place earphones back into charging case, earphones start to be charged when you see a blue LED flash on earphones. Close the lid, earphones may take up to 1.5 hours to get fully charged when at 0% battery.



CHARGE THE CASE

It is recommended that you use the provided charging cable, connect USB-A end to 5V power adapter or other devices, connect USB-C end to the charging port of the case.

Note: It takes around 2 hours to get the case fully charged when at 0% battery.



11

CLEANING

1. Wipe down surfaces with a cleaning cloth.

2. Never use abrasive pads to clean device.

3. Avoid using liquids to clean device.

4. Wipe the pogo pins with appropriate amount of alcohol soaked in cotton swab.

12

Specifications

Weight

0.19 lb

Product Dimensions (L x W x H)

3.73 x 2.35 x 1.12 inches

94.8"59.8"28.5mm

13

Troubleshooting

Problem	Prevention/Solution
Cannot find "onn TWS Open-Ear Pro" on my Bluetooth device.	• Ensure Bluetooth function is enabled on your device. • Double check if the earphones already connected with last-time paired device. • Press & hold 2 seconds PAIRING BUTTON on charging case, to let it enter to pairing mode. Or press & hold 10 seconds to reset this product.
Sound is not produced.	• Ensure you have earphones connected with Bluetooth device, and increase volume from your Bluetooth device. • Place earphones back to charging case, press & hold PAIRING BUTTON for 10 seconds to reset it.
Cannot power on	• Charge earphones & charging case for enough time. • Clean the pogo pins of both earphones and charging case, ensure them contact well.

14

Cut line
Fold line
Copy safe area
Outside Bleed
Glue area