












WM_ONN
Cannice
100150848
TWS Sport Hook Gen 2
OPT01_QSG
06/19/2025

<div><div>onn</div><div>USER GUIDE</div><div>Wireless Sport Earbuds</div><div></div><div>AAMN1W100150848/AAGHTR100150848-EN-05062025</div></div>	<div>Contents & Information</div> <div>CONTENTS & INFORMATION 1</div> <div>Features 2</div> <div>OVERVIEW 3</div> <div>SAFETY PRECAUTIONS 5</div> <div>OPERATION 7</div> <div>First time setup 7</div> <div>Power on & Power off 8</div> <div>Pairing 9</div> <div>Play music 10</div> <div>Phone calls 10</div> <div>Charging 11</div> <div>CLEANING & CARE 13</div> <div>Cleaning 13</div> <div>SPECIFICATIONS 13</div> <div>TROUBLESHOOTING 14</div> <div>1</div>	<div>Features</div> <div>1. HD sound with deep bass and clear treble</div> <div>2. Multipoint— connect to 2 devices</div> <div>3. Google Fast Pair (Android™ only)</div> <div>4. Dual built-in microphones with environmental noise cancellation in each earphone</div> <div>5. Up to 9+ hours of playtime per charge</div> <div>6. 40 hours of total playtime (with charging case)</div> <div>7. Bluetooth range: 10m/32.8ft</div> <div>8. IP55 dust and water/sweat resistant* (applies to the earphones, not to the charging case)</div> <div>2</div>	<div>Overview</div> <div></div> <div>LED INDICATOR</div> <div>CHARGING CASE</div> <div>CHARGING PORT</div> <div>When earbud been placed back to charging case</div> <div>Battery > 30% : Blue LED stays bright for 3 seconds</div> <div>Battery <= 30% : Blue LED flashes 3 time</div> <div>3</div>	<div>CHARGING CABLE</div> <div>EARBUDS</div> <div>Volume Up</div> <div>Next Track</div> <div>LED INDICATOR</div> <div>Volume Down</div> <div>Previous Track</div> <div>End/Reject Call</div> <div>Media Play/Pause</div> <div>Power On/Off</div> <div>4</div>	<div>Safety Precautions</div> <div>FCC Statement</div> <div>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</div> <div>-Reorient or relocate the receiving antenna.</div> <div>-Increase the separation between the equipment and receiver.</div> <div>-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</div> <div>5</div>	<div>Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:</div> <div>1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</div> <div>FCC RF exposure statement:</div> <div>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</div> <div>Warning:</div> <div>Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</div> <div>Need help? We are here for you everyday from 7a.m.-9p.m. CST. Give us a call at 1-888-516-2630.</div> <div>Produced for Walmart Inc., Bentonville, AR 72716</div> <div>Ver.01 05/06/25</div> <div>FCCID :2ADTV-50848</div> <div>6</div>	<div>onn</div> <div>For product assistance WE CAN HELP</div> <div>1-888-516-2630</div> <div>7 DAYS/WEEK</div> <div>7:00am- 9:00pm CST</div> <div>THIS GUIDE CONTAINS IMPORTANT SAFETY INFORMATION.</div> <div>PLEASE READ AND KEEP FOR FUTURE REFERENCE.</div> <div>Find more at Walmart.com</div> <div>Manufactured in India for: Walmart, Inc.</div> <div>7</div>
---	--	--	--	---	--	---	---

<div>Operation</div> <div>FIRST TIME SETUP</div> <div>Device may need to be charged before use.</div> <div></div> <div>CAUTION</div> <div>Only use a USB charging device that is 5V DC output.</div> <div>1. Remove the protective films before the first use, then place both earbuds back into charging case.</div> <div>2. Then take both earbuds out of the charging case, earbuds will enter pairing mode automatically.</div> <div>3. Find "onn TWS Sport Gen2" in device Bluetooth settings.</div> <div>7</div>	<div>POWER ON & POWER OFF</div> <div>1. POWER ON</div> <div>Open the charging case and take earbuds out, earbuds will power on and connect to last paired device automatically.</div> <div></div> <div>2. POWER OFF</div> <div>Place earbuds back to charging case and close the lid, earbuds will power off automatically.</div> <div></div> <div>Note: Without the charging case, you can also manually power on earbud by press and hold round button for 3 seconds, manually power off earbud by press and hold round button for 4 seconds.</div> <div></div> <div>8</div>	<div>PAIRING</div> <div>HOW TO PAIR WITH ANOTHER DEVICE</div> <div>When earbuds are connected to your current device, disable Bluetooth on your current device, earbuds will enter pairing mode immediately.</div> <div>Or you can use MULTIPOINT to pair with another device.</div> <div>HOW TO PAIR WITH 2 DEVICES SIMULTANEOUSLY (MULTIPOINT CONNECT)</div> <div>When earbuds are connected to the first device, press and hold the "+" and "-" buttons simultaneously for 4 seconds to trigger MULTIPOINT, now you can search it from your second device and connect it, then your both devices are connected to the earbuds.</div> <div></div> <div>9</div>	<div>PLAY MUSIC</div> <div>Control</div> <div>Action</div> <div>Result</div> <div>Press & Hold 2 sec</div> <div>x1 Press</div> <div>Next track</div> <div>Increase Volume</div> <div>Press & Hold 2 sec</div> <div>x1 Press</div> <div>Previous track</div> <div>Decrease Volume</div> <div>x1 Press</div> <div>Play / Pause</div> <div>x2 Press</div> <div>Voice assistant</div> <div>PHONE CALLS</div> <div>Control</div> <div>Action</div> <div>Result</div> <div>x1 Press</div> <div>Increase Volume</div> <div>x1 Press</div> <div>Decrease Volume</div> <div>Press & Hold 2 sec</div> <div>Mute On/off</div> <div>x1 Press</div> <div>Answer/End the call</div> <div>Press & Hold 2 sec</div> <div>Reject incoming call</div> <div>10</div>	<div>CHARGING</div> <div>CHARGE THE EARBUDS</div> <div>Place earbuds back into charging case, the LED light on earbuds will start flashing, means earbuds are being charged successfully.</div> <div>Close the lid, it may take up to 1.5 hours to get earphones fully charged when at 0% battery.</div> <div></div> <div>About 1.5 hours</div> <div>11</div>	<div>CHARGE THE CASE</div> <div>It is recommended that you use the provided charging cable, connect USB-A end to 5V power adapter or other devices, connect USB-C end to the charging port of the case.</div> <div>Note: By using the provided charging cable, it takes around 3 hours to get the case fully charged when it at 0% battery.</div> <div></div> <div>CHARGING PORT</div> <div>Charging : White LED is flashing</div> <div>Fully charged : White LED stays bright</div> <div>12</div>	<div>Cleaning & Care</div> <div>CLEANING</div> <div>1. Wipe down surfaces with a light cloth.</div> <div>2. Never use abrasive pads to clean device.</div> <div>3. Avoid using liquids to clean device.</div> <div>4. Wipe the pogo pins with appropriate amount of alcohol soaked on cotton swab.</div> <div>13</div>	<div>Troubleshooting</div> <div>Problem</div> <div>Prevention/Solution</div> <div>Cannot find "onn TWS Sport Gen2" on my Bluetooth device.</div> <div>•Ensure Bluetooth function is enabled on your device.</div> <div>•Double check if the earbuds already connected with last-time paired device.</div> <div>No sound in one earbud, or the L and R earbuds can't be paired with each other.</div> <div>•Need to reset the earbuds. Firstly, you need to forget these earbuds from your device Bluetooth settings, then place both earbuds into the case, press and hold the round button of both earbuds simultaneously for 10 seconds, when you see Blue LED on both earbuds staying bright for 2 seconds, it means earbuds are reset successfully. Now you can take earbuds out from charging case, and they will enter pairing mode automatically, please connect them and the problem will be solved.</div> <div>•Charge earbuds and charging case for enough time.</div> <div>Cannot power on</div> <div>•Clean the pogo pins of both earbuds and charging case, ensure them contact well.</div> <div>14</div>
---	--	---	---	--	---	--	--

Cut line
Fold line
Copy safe area
Outside Bleed
Glue area