



<h3>Call</h3> <p>Answer a call Press the Multifunction button or Volume "+" or Volume "-" once.</p> <p>Reject a call Press and hold the Multifunction button for about 2 seconds.</p> <p>End a call Press the Multifunction button once.</p> <p>End current call and answer new call When a new call rings during a call, press the Multifunction button once to answer new call and end current call simultaneously.</p> <p>On hold current call and answer new call When a new call rings during a call, Double the Multifunction button to hold current call and answer new call.</p> <p>Reject the new call hold the current call During the call there is a new call, press and hold the multifunction button for about 2 seconds to reject a new call, keeping the active call.</p>	<h3>Music</h3> <p>(Need media player support).</p> <p>Mute on/off Press the Volume "-" for about 2 seconds to mute on/off.</p> <p>Switch between the earphone and phone Press the multifunction button for about 2 seconds during a call, the call will be switched to the mobile phone, redo this operation again, the call will be switched to the earphone.</p> <p>Redial the last call Double-press multifunction button in standby mode or streaming. The mobile phone will redial the last call number.</p> <p>Switch Music and Call When a call rings during a music playing, the music automatically pauses to allow you to answer or ignore the call. Once the call is ignored or ends, the music is resumed.</p> <p>Voice dial (Need phone support) In standby mode press and hold the multifunction button for about 2 seconds wait for phone prompt and then tell the phone to dial the name of a stored contact.</p>	<h3>Basic operation</h3> <p>Status indicator</p> <table border="1"> <thead> <tr> <th>Instruction</th> <th>LED status</th> <th>Voice prompts</th> </tr> </thead> <tbody> <tr> <td>Power on</td> <td>Stay white about one second</td> <td>Power on</td> </tr> <tr> <td>Power off</td> <td>Stay red about two seconds</td> <td>Power off</td> </tr> <tr> <td>Standby</td> <td>Blink white once every 5 seconds</td> <td>/</td> </tr> <tr> <td>Pairing</td> <td>Flashes red and white alternately</td> <td>Pairing</td> </tr> <tr> <td>Incoming call</td> <td>Flashes white quickly</td> <td>Toot</td> </tr> <tr> <td>Battery low</td> <td>Blink red</td> <td>Battery low</td> </tr> <tr> <td>Charging</td> <td>Stays on red while charging</td> <td>/</td> </tr> <tr> <td></td> <td>Stays on white after fully charged</td> <td></td> </tr> </tbody> </table> <p>Music play / pause Press Multifunction button once to play / pause music. (Some phones may require you to start a media player first).</p> <p>Track back/forward Press the Volume "-" for 2 seconds once to skip track backward, press Volume "+" for 2 seconds once to skip track forward.</p> <p>Volume up/down Press the volume "+" to turn volume up Press the volume "-" to turn volume down</p> <p>Power on Press and hold Multifunction button for about 3 seconds. The earphone says "power on" and the LED flashes white one second</p> <p>Power off Press and hold Multifunction button for about 5 seconds. The earphone says "power off" and the LED flashes red two seconds.</p> <p>Tips: When the distance between the earphone and phone is beyond effective range, earphone disconnects with phone. Earphone will power off automatically once no active for 15 minutes.</p>	Instruction	LED status	Voice prompts	Power on	Stay white about one second	Power on	Power off	Stay red about two seconds	Power off	Standby	Blink white once every 5 seconds	/	Pairing	Flashes red and white alternately	Pairing	Incoming call	Flashes white quickly	Toot	Battery low	Blink red	Battery low	Charging	Stays on red while charging	/		Stays on white after fully charged		<p>Enable voice prompts: enter pairing mode: Press the volume "+" button for 3 seconds, the white LED lights flash 3 times;</p> <p>Disable voice prompts: enter pairing mode: Press the volume "-" button for 3 seconds, the red LED lights flash 3 times.</p> <p>Clear paired list Make sure the earphone is turned off, press and hold the Multifunction button until the LED indicator flashes red and white alternately (About 7 seconds), then release Multifunction button. Press volume "+" and volume "-" button at the same time until LED flashes blue, then LED flashes red and white alternately, the paired list was cleared, the earphone will enter pairing mode after power on next time.</p> <p>Hard reset If the earphone cannot be turned on even when fully charged or does not respond during use, follow the instructions below to reset it. 1. While pressing and holding the multifunction button, connect the earphone to your PC's USB port or a USB power adapter with the charging cable. 2. Keep pressing and holding the Multifunction button until the earphone turns on. The earphone is now reset.</p>	<h3>Safety and care</h3> <p>Using earphone at high to moderate volumes for extended periods of time will result in permanent hearing damage. It is advised you keep volume levels moderate to low at all times for your safety.</p> <p>Do not use while driving a car, cycling, operating machinery, or performing other activities that require hearing surrounding sounds.</p> <p>Do not use earphone in thunderstorm weather, the earphone may not work properly in the condition, and increase the risk of being hit by lightning.</p> <p>Earphone may not work properly under high temperature or high humidity conditions.</p> <p>Do not use any corrosive cleaner/oil to clean the earphone.</p> <p>If the earphone comes in contact with liquids, quickly wipe away. If submerged in water, do not turn the earphone on until completely dried. Tips: liquid submersion voids the warranty.</p> <p>Keep the earphone and packaging out of reach of children.</p>
Instruction	LED status	Voice prompts																													
Power on	Stay white about one second	Power on																													
Power off	Stay red about two seconds	Power off																													
Standby	Blink white once every 5 seconds	/																													
Pairing	Flashes red and white alternately	Pairing																													
Incoming call	Flashes white quickly	Toot																													
Battery low	Blink red	Battery low																													
Charging	Stays on red while charging	/																													
	Stays on white after fully charged																														

<h3>Start here</h3> <p>Following items are included</p>  <p>USB cable</p> <p>Ear cushions</p>	<h3>Product overview</h3> <p>1. Volume - / Track back 2. Multifunction button 3. Volume + / Track forward 4. Charge jack 5. Talking mic 6. Battery 7. Status indicator</p>  <p>Charging</p> <p>Your new earphone has enough power to pair and make a few calls. It takes 2 hours to fully charge the earphone, while charging, the battery indicator light is red, the indicator light flashes white once charging is complete.</p> <p>Note: The lifetime of the battery will be significantly reduced if your earphone is left uncharged for a long period. We recommend that you recharge your earphone at least once a month.</p>	<h3>Pairing</h3> <p>Pair one phone</p> <p>Windows Phone 8 a. On your phone, open the Settings menu. b. Select Bluetooth. If Bluetooth is off, turn it on. The Phone will search for new devices automatically.</p>  <p>iPhone a. On your phone, open the Settings menu. b. Select Bluetooth. If Bluetooth is off, turn it on. The iPhone will search for new devices automatically.</p>  <p>Android phone a. On your phone, open the Settings menu. b. Select Bluetooth (For old Android phone, Bluetooth is found in the Wireless & Networks). If Bluetooth is off, turn it on. Select Search for Devices if your phone does not automatically search for new devices.</p> 	<p>Pair another phone</p> <p>Multipoint technology enables you to pair headset to two phones at the same time and take calls from either:</p> <p>1. Make sure the earphone is turned off and within 1 meter of your phone, press and hold the Multifunction button until the LED indicator flashes red and white alternately (About 7 seconds), then release Multifunction button. 2. Activate Bluetooth on your phone (See below for more details).</p> <p>iPhone a. On your phone, open the Settings menu. b. Select Bluetooth. If Bluetooth is off, turn it on. The iPhone will search for new devices automatically.</p>  <p>Android phone a. On your phone, open the Settings menu. b. Select Bluetooth (For old Android phone, Bluetooth is found in the Wireless & Networks). If Bluetooth is off, turn it on. Select Search for Devices if your phone does not automatically search for new devices.</p> 	<p>Warning</p> <p>Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <p>(1) This device may not cause harmful interference, (2) This device must accept any interference received, including interference that may cause undesired operation.</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/TV technician for help. <p>FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.</p>
--	---	--	--	--

cannice

RING COLLAR
MUSIC Bluetooth Earphone

W5 INSTRUCTION