

Statement

1. Any form of reproduction, transfer, distribution and storage of any content of this manual is strictly prohibited without the prior written permission of our company.
2. Though Our employee have been striving to make this manual accurate and complete in the process of preparation, but no guarantee that any errors or omissions are not existed, and our company will not take the responsibility for any possible errors or omissions.
3. We will retain the rights of modification and improvement for any of products described in this manual without prior notice in order to complying with sustainable development strategy.
4. Under any circumstances, we will not undertake the responsibility of any data or income loss, or any special, casual, incidental or indirect loss, no matter what the loss caused by any reason.

Precaution

This section is for our users to use Bluetooth watch properly and ensure Bluetooth watches in good performance, please read and complying as follows carefully.

1. Do not impact device violently.
2. Do not contact benzene, thinner chemicals etc.
3. Keep away from the strong magnetic field, electric field.
4. Please avoid direct light or heating appliances.
5. Do not disassemble, repair, transform by yourself.
6. Waste packaging, batteries, old electronic products, please classify and handle them properly.




Brief introduction

After matching with the mobile phone, the Bluetooth watch will have a vibrating alert and a caller ID display when there is an incoming call, and the Bluetooth watch also has 24-hour time display. You can perform the following actions by using a Bluetooth watch:

- Call Handling.
- Pedometer.
- Alarm Clock.
- Perform other to-do list.

Accessories Overview

Pictures:



User Manual

- 1.Power On/Off/Return/Hang up: Long press to Power on/off, short press to return to previous menu and hang up.
- 2.Previous: Press and return to previous page.
- 3.Next: Press and go to next page.
- 4.Confirm/Answer: Enter the selected page or answer the calls.
- 5.DC port (Touch Spot) : Battery charging.
- 6.Data cable: For battery charging and software upgrading.
- 7.Product specification.
- 8.Warranty card. (Product Qualification Certificate)

Battery charging

You have to charge about 1.5 hours before using the Bluetooth watch at the first time, please use the matching charger only.

1. Insert the charger plug into the outlet.
2. Insert the data cable into an USB charger port. (Or connect with the computer USB port) DC 5V
3. Insert the other end of data cable into the Bluetooth watch charging port.

Main Menu Introduction

• Standby interface:

To view the date, time, battery condition and weather conditions, quickly view Wechat messages, text messages, missed calls in standby interface.

• Messaging:

- 1) Notification: To check the Wechat messages.
- 2) Inbox: To check the received SMS messages.
- 3) Missed Calls: To check missed calls.

• E-Power:

- 1) Check: Press the Select button to start/pause pedometer, you can view the current walking distance and calorie consumption.
- 2) Settings: Set personal information to calculate the walking distance and calorie consumption accurately.
- 3) Goal: Set personal daily exercise goals
- 4) In Total: To check the sum of steps, distance and calorie consumption.

- **Bluetooth:**

- 1) Bluetooth Switch: Turn on/off of the Bluetooth watch, disconnect with mobile phone at first before turning it off.
- 2) Bluetooth Name: To view the Bluetooth name.
- 3) Connected Device: Automatically reconnect with mobile phone after first disconnection.
- 4) Contacts Synchronization: Synchronize with the phone book.
- 5) Disconnection: Disconnect current connection with mobile phone.
- 6) Empty Connection: Clear all current connections.

- **Search:**

- 1) Search for mobile phone: Sustained vibration reminder with music playing on the mobile phone when the watch Bluetooth turns on, which is easy to find the mobile phone.
- 2) Mobile phone anti-lost: Sustained vibration reminder with music playing on the mobile phone once it stays away from the Bluetooth watch for a certain distance in order to prevent mobile phone from loss.

(This function supported by ****APK)

- **Remote Camera:**

Control your phone to take pictures by using the watch.

(This function supported by ****APK)

- **Time Management:**

- 1) Alarm Clock: Sustained vibration reminder on the watch when the Alarm Clock starts.
- 2) Date and Time: Can modify date time and time format.

Time Synchronization: Synchronize with the phone time (This function supported by ****APK)

- **Dial Settings:**

There are four dials are optional for personal preferences

- **Settings**




- 1) Language: Language can be set to English and Simplified Chinese, Default Simplified Chinese.
- 2) Profiles: Vibrate or Silent only.
- 3) Version: To view current software version No.
- 4) Reset: Factory Reset/Restore to factory settings.

Install Necessary Apps


• In order to give a full play to the function of Bluetooth watch on your mobile phone, you must download the apps to your mobile phone. If you cannot to install it, you will not make full use of your Bluetooth watch.

1. Scan the QR code on the packaging.
2. Downloading Path: <http://download-erunning.yy845.com/>


A. Users need set up some basic information for the first time use after installed APK.



B. Set up personal exercise planning:



C. Link to BT device TJ01




Can quick links to device TJ01 and also can switch to our company smart wearable devices page after slide screen to right side

Users can see the battery reserve information under the same page


Click "Synchronization with device" icon, the TJ01 data can synchronized to the phone.

Click "Cloud data synchronization" icon, users can keep the data on phone synch to the cloud server which is use for personal exercise data ranking(database).


D. Record daily exercise data interface(Main Interface)





E. Accumulative fitness database statistic interface(Data Center)



F、Fitness Scheme



G、Fitness data sharing



H、Sports ranking(play with the general sports enthusiast)

My ranking		
Week	Month	Rank/Day
1	陈	44345 steps
2	小毛儿	41391 steps
3	Kam曾	36228 steps
4	sampson (龙)	34263 steps
5	lake	27808 steps
6	so smart	21984 steps
7	叫唛啊荷	15186 steps

You have no movement record to rank.

In addition, there also have many interesting functions in our APK, such as: Records of sports activities, Moving pictures shoot, sharing personal activities...etc.

More fun, More functions, waiting for you discovery

FAQ

Can Not Be Connected To The Mobile Phone.

• Make sure the watch has been charged and within range of the phone connection, the recommended maximum distance is 10 meters without any solid object in the middle , check the phone's Bluetooth connection, please reconnect it if necessary.

Power Off Automatically.

• Low Battery. The Bluetooth Watch will be text reminder when the power is low, meanwhile, please charge the watch.

Unexpected Action

• Reset The Watch. Reset the watch under the menu option.

FCC Warning

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency Energy and, if not installed and used in accordance with the instructions, may cause harmful interference to Radio communications. However, there is no guarantee that interference will not occur in a particular Installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions

(1) this device may not cause harmful interference,

and (2) this device must accept any interference received, including interference that may cause undesired operation.