

1、 SAR Test Setup

Front view




Rear View



Front Side 0mm



Rear Side 0mm



Right Side 0mm



Top Side 0mm



2、 PD Test Setup



Back Side, the distance from EUT to the Phantom is 0mm