

USER GUIDE

Wireless Earphones




AABLU100002890_EN_11152023

Contents & Information

- CONTENTS & INFORMATION
 - Features
 - OVERVIEW
 - SAFETY PRECAUTIONS
 - OPERATION
 - First time setup
 - Power on & Power off
 - Pairing
 - Play music
 - Phone calls
 - Charging
 - CLEANING & CARE
 - Cleaning
 - SPECIFICATIONS
 - TROUBLESHOOTING

Overview



Safety Precautions

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

--Increase the separation between the equipment and receiver.

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

FCC RF exposure statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Need help? We're here for you everyday from 7am-9pm.

CST. Give us a call at 1-888-56-2630.

Produced for Walmart Inc.,

Bentonville, AR 72701

For product assistance:

WE CAN HELP

1-888-56-2630

THIS GUIDE CONTAINS IMPORTANT SAFETY INFORMATION.

PLEASE READ AND KEEP
FOR FUTURE REFERENCE.

on.

For product assistance:

WE CAN HELP

1-888-56-2630

THIS GUIDE CONTAINS IMPORTANT SAFETY INFORMATION.

PLEASE READ AND KEEP
FOR FUTURE REFERENCE.

Find more at Walmart.com

Manufactured in Vietnam for Walmart, Inc.

Operation

FIRST TIME SETUP

Device may need to be charged before use.



POWER ON & POWER OFF

POWER ON

Press the multifunction button for about 2 seconds and the blue indicator flashes for 2 seconds.



POWER OFF

Press the multifunction button for about 3.5 seconds and the red indicator flashes for 2 seconds.





Remove the protective film before the first use, then power on the headphone and it will go to pairing mode automatically. Headphone will automatically reconnect to the last paired device when powered on next time.

CAUTION
Only use a USB charging device that is 5V DC output.

PAIRING

- If this is the first time connecting your headphones, follow FIRST TIME SETUP instructions.
- If you want to pair your headphones with a new device, please disconnect it from the Bluetooth list of your current device. Once disconnected, it will go to pairing mode automatically.





PLAY MUSIC

Control	Action	Result
	x 1 Press	Play / Pause
	x 2 Press	Siri / Google Assistant
	x 1 Press	Hang up
	x 1 Press	Increase Volume
	Press & Hold 2 sec	Next Track
	x 1 Press	Decrease Volume
	Press & Hold 2 sec	Previous Track

PHONE CALLS

CHARGE THE Headphones

- It is recommended that you use the provided charging cable.
- The headphones will automatically power off when charging. It may take up to 2 hours to get it fully charged when at 0% battery.



CHARGING PORT
About 2 hours
5V 0.5A

Charging: Red LED light is on
Fully charged: Blue LED light is on

Note: 10 mins charge can provide around 3 hours playtime.

Cleaning & Care

CLEANING

- Wipe down surfaces with a cleaning cloth.
- Never use abrasive pads to clean device.
- Avoid using liquids to clean device.

Problem	Prevention/Solution
Can't find "on-ear" on my Bluetooth device.	Ensure Bluetooth function is enabled on your device.
Double check if the headphones already connected with last-time paired device.	
Sound is not produced.	Ensure you have headphones connected with Bluetooth device, and increase volume from your device.
Can't power on.	Charge headphones for enough time.

Specifications

Weight
0.32 lb

Product Dimensions (L x W x H)
6.7 x 2.5 x 6.7 inches
172 x 72.1 x 69.5 mm