

 BFS-33X 2.1 CHANNEL WIRELESS MULTIMEDIA LED DANCING WATER BLUETOOTH SOUND SYSTEM  OWNER'S MANUAL	NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
---	--

REAR SPEAKER CONNECTION

SPECIFICATIONS

Power Output	5W+3W*2
Supply Voltage	DC 5V 2A
Bluetooth	5.0
Material	Acrylic + ABS
Base unit	ø220mm*325.5mm
Treble unit	ø90mm*265mm
Bass unit	2330g ± 20g
Treble unit	2*(370g ± 20g)
Frequency Response	75Hz-18KHz
S/N	72dB
Main driver unit	4 inches
Satellite driver unit	1.75 inches
Operation Temperature	32°F - 104°F
Storage Temperature	5°F - 140°F
Storage Humidity	20%-90% RH
20 Multi colored LEDs in total (Red, Yellow, Blue, Green)	
Buttons : Volume/Next, Volume/Previous, Play/Pause, Power On/Off	
Accessories: 3.5mm Audio Cable, 5V 2A Power adapter	
Bluetooth and AUX connections	

Note: Product are improved continuously. We reserve the right to modify the product and specifications without prior notice.

FOR WARRANTY INFORMATION AND FEEDBACK,

PLEASE VISIT

WWW.BEFREESOUND.COM

Support & Warranty

(323) 306-3885

4 | BFS-33X | REAR SPEAKER CONNECTION

SPECIFICATIONS | BFS-33X | 9

PAIRING A DEVICE WITH BLUETOOTH® A Bluetooth® enabled device must first be paired with the sound system before any music can be streamed. To pair a Bluetooth® enabled device with the sound system: 1. Turn the speakers on. 2. Ensure that the Bluetooth® is enabled on your device. Enable it if it isn't. 3. Use your device to search for nearby Bluetooth® devices. (This function is usually in the Bluetooth settings menu; refer to your device's instruction manual to learn more.) 4. Select "BF533X" in the list of available devices on your phone. 5. Once the pairing is successful, the sound system will play a sound alerting the user that music is now ready to be streamed. <i>If the pairing process fails, turn the speakers off and repeat the process. For faster trouble-free pairing, we recommend keeping the device within 3 feet of the speakers while pairing.</i>	USING THE SPEAKERS When the speakers are connected to a Bluetooth® device, you can stream music wirelessly to the speakers from the device. For convenience, you can control the music directly from the main speaker unit with the following buttons:  Control light and water jumping  Decrease the volume level (press)  Increase the volume level (press)  Skip to the previous track (press and hold)  Skip to the next track (press and hold)  Turn the speaker on/off (press) USING THE AUX INPUT CONNECTOR You can connect devices without Bluetooth® by using the AUX 3.5 mm cable. 1. Use the included AUX cable to connect the device's headphone or line-out jack to the auxiliary input found at the back of the main speaker unit. 2. A cue-tone will indicate that the AUX mode is now enabled. 3. Set the device volume to 80% of its maximum and start playback from your device. If the music doesn't stream automatically even after pressing start on your device, try pressing the  button on the main unit and the music should start playing.
---	--