


NC-25

The Wireless Active Noise Cancelling Headphones



The Wireless Headphones is developed to deliver super round quality with Bluetooth 4.1V CSR 8635

The Active Noise Cancelling technology reduce surrounding noise up to 20dB and let you enjoy pure music without distraction

Specification:

Speaker Unit: 40mm

Magnet: Neodymium

Sensitivity: 105+/-3dB

Impedance: 32 ohms+/-10%

Frequency range: 20~20KHz

Active cancellation : Up to 15~20dB between 100~1kHz


Blue-tooth version: V4.0

operation distance: 10m

Power: 3.7V 360mah

Working Hour: Music Playing 12 hrs

Function Overview:



ANC Noise Cancelling On/Off Button

● Multifunction Button (Bluetooth On/Off, Make/Answer/End / Reject Call, Pause Wireless Only)

◀ Volume Down/Previous Song (Wireless Only)

▶ Volume Up/ Next Song (Wireless Only)

Operation:




Noise Cancelling:

- 1, Press the ANC Button ON, the Noise Cancelling Indicator is green.
- 2, After turn the noise cancelling on, you may hear a slight hissing noise, this is normal`will cease after a few seconds.
- 3, When using noise cancelling feature, if the battery is off, the green indicator is off, if you want to continue using noise cancelling feature, you need charge the battery. If you use wired connection you can continue use the headphones

Wireless Operation:

- 1, Press the Multifunction Button for one second, you will hear "Power On" and "BEEP" with the Blue Indicator Is Blinking. and the Bluetooth is in pairing mode.
- 2, Enable the Bluetooth on your mobilephone or the device you want to connect and scan/search for new device.
- 3, When NC-25 is found, select and connect, you will hear voice remind "Connected". and the Blue indicator will flash every five seconds. The connection is completed.

Play Music:

- 1, Press the Multifunction Button  once to play music, and press it again to pause.
- 2, Press the Volume Down/ Previous Song Button  once to play previous song, long press to reduce the volume.
- 3, Press the Volume Up/Next Song Button  once to play next song, long press to increase volume.

Call Functions:

Call Answer: Press the Multifunction Button once to answer, and press again to end.
Last number redial: in standby mode, press the Multifunction Button twice to redial. .

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.