

QUICK GUIDE

CHECK FOR SOFTWARE UPDATES ON WEBSITE
www.interphone.com

WARNING ON THE BATTERY OF THE PRODUCT

Fully charge the battery before using the product for the first time.
Do not store the Product without charging it. Failure to do so may cause irreversible damage to the battery capacity. Charge the battery every TWO months.

WARNING ON THE WATER RESISTANCE OF THE PRODUCT

The external unit (control unit), connected to the audio kit, can be immersed in a meter of fresh water for a maximum of 30 (thirty) minutes.

Despite this, the device is not immune to greater stress, such as prolonged immersions or high pressure water jets.

Using the product during intense meteorological phenomena, at high speeds, may be equivalent to subjecting the product to a high pressure jet.

FOLLOW ALL SUGGESTIONS CAREFULLY TO AVOID DAMAGING THE DEVICE:

Do not immerse the product in fresh water which is more than a metre deep for more than 30 minutes.


Do not store the product when still wet: dry it with a clean, soft cloth.

Do not expose the product to salt water or ionised water, drinks or other liquids.



If the device is exposed to liquids other than fresh water, wash the device with cold fresh water and dry it carefully with a clean, soft cloth.

Do not expose the product to high pressure water jets.



CHAPTER 1 – COMPOSITION OF THE KIT



Bluetooth unit





CHAPTER 2 – INSTALLATION INSTRUCTIONS





If possible, remove the two cushions or padding

Locate the area in correspondence with the ear



Position the strips of Velcro for the speakers

Place the speakers




Choose the microphone to use:


Filp-up/jet helmet

Full face helmet


6 Choose the bracket to use, to be attached on the left side of the helmet:




Sticker



Bracket



Re-install the cushions



Install the control unit

(!) Warnings on installation:

1. The centre of the speakers must be placed in correspondence with the ears, as close as possible.



2. The marking "MIC" on the microphone must be directed towards the mouth.






CHAPTER 3 - BATTERY CHARGE

Insert the micro USB charging cable in the special intercom connector, as shown in the picture. Connect the cable to a standard USB charger.

LED indications:

- orange LED: charging.
- green LED: fully charged



CHAPTER 4 - BASIC CONFIGURATION

Turn the device on

Press **MFB** until the blue LED comes on.

Turn the device off

Press **MFB** until the red LED lights up and the device turns off.

Activate / Deactivate automatic volume control

1. With the device off, press **MFB** until the second beep. Led will flash red/blue.
2. To activate, press **Volume +** until the first beep. Led will flash blue for 4 seconds.
3. To deactivate, press **Volume -** until the first beep. Led will flash red for 4 seconds.

Activate / Deactivate phone calls voice answer

1. With the device off, press **MFB** until the second beep. Led will flash red/blue.
2. To activate, press **Volume +** until the second beep. Led will flash blue for 4 seconds.
3. To deactivate, press **Volume -** until the second beep. Led will flash red for 4 seconds.

Factory Reset

With the device off, press together **MFB** and **Volume +** and **Volume -** until the device switches on. All settings and pairings will be erased.

CHAPTER 5 - TELEPHONE / GPS

Pairing

1. With the device off, press **MFB** until the second beep. Led will flash red/blue.
2. Start searching for new devices on the mobile phone / GPS
3. Select the intercom on the phone / GPS "interphone shape".
4. Once the pairing has been confirmed, the LED will flash BLUE twice, every three seconds.

Answering a call

Just say loudly "HELLO" or short press **MFB**.

Voice dial

Short press **MFB**.

Radial last number

Double press **MFB**.

CHAPTER 6 - MUSIC

Enable/disable playback from the phone

Press **MFB** until the second beep.

Next track

On music playback, press **Volume +** until the first beep.

Previous track

On music playback, press **Volume -** until the first beep.

Share the music with another intercom

On music playback, press **Volume +** until the second beep.

To stop sharing, press **Volume -** until the second beep.

CHAPTER 7 - INTERCOM

Pairing with another Interphone device (for the first time only)

1. With both the intercom devices off, on each unit press power-on button until led will flash red/blue.
2. Short press **MFB** button on one Interphone SHAPE, units will pair and connect.

Pairing with a NON-Interphone device (for the first time only)

1. In the NON-Interphone unit, start the telephone search/pairing mode; refer to the user manual of the intercom to be paired.
2. With Interphone SHAPE off, press **MFB** until led will flash red/blue.
3. Short press **MFB** button on Interphone SHAPE, units will pair and connect.

Two way intercom talk

On one unit only, press **MFB** until the first beep.

To stop communication, on one unit only, press **MFB** until the first beep.

SPECIFICHE TECNICHE

Bluetooth® compliance:

Bluetooth v.3.0 - Class II
HFP A2DP AVRCP

2.402 – 2.480GHz

7dBm EIRP

0 – 45°C

10 - 40°C

36x78x18

61 g

Up to 10 meters

12 h

700 h

3 h

Lithium-ion rechargeable

Frequency:

Power:

Operating temperature:

Charging temperature:

Dimensions mm:

Weight:

Capacity:

Talk time:

Stand-by time:

Charging time:

Battery type:



WARNING: To prevent possible hearing damage, do not listen at high volume levels for long periods.

