



WALKIE TALKIES

AGES 5 AND UP

UP TO 329 FT
COMMUNICATION
DISTANCE

BATTERY OPERATED

OFFICIAL LICENSED PRODUCT OF THE U.S. ARMY

STYLE#USA20022



7 104131 20022 14
MADE IN CHINA

By federal law, licensing fees paid to the U.S. Army for the use of its trademarks

provide support for the Army Trademark Licensing Program.

and do not license the U.S. Army name, U.S. Army logo, Welfare and

Recreation programs, U.S. Army name, trademarks and logos are protected

under federal law and used under license by Lollipop Toys.

Specifications and colors may vary as shown

Keep this information for any possible correspondence in future

years. Lollipop Toys is not responsible for children and pets.

This and all Lollipop Toys meet or exceed toy safety standards

CONFORMS TO ASTM F963-17



Learn more about what it
means to be a U.S. Army Soldier at
www.goarmy.com



REAL WORKING WALKIE TALKIES

HOW TO OPERATE YOUR TRANSCEIVER

1. Remove battery door and put in 9V 006P size battery (not included)
2. Turn the "On-Off" switch to "On" position. Your transceiver is now ready to operate.
3. Press the "PUSH TO TALK" switch for transmitting.
4. Hold the microphone close to your mouth.
5. When transmitting, speak clearly in a normal voice, holding the set about 3 inches from your mouth.
6. Best transmission and reception are obtained when the antenna is held in a vertical position.
7. Operate range up to 300 feet, line of sight, in open area without obstruction & interference.

CAUTION

- 1. Your transceiver set has been fully adjusted prior to shipment from the factory and is not to be touched unless necessary.
- 2. When the signal becomes weak, it is time to change battery.
- 3. After use, always return the "On-Off" switch to the "Off" position.
- 4. Keep your set in a dry and clean place.

► Non-rechargeable batteries are not to be recharged.
► Electrolyte is extremely dangerous to skin and eyes.
► The supply terminals are not to be short-circuited.
► Do not expose the battery to fire.
► Do not alkaline, standard (carbon-zinc) or rechargeable batteries.
► Do not use batteries that are not recommended or are used.
► Batteries are to be inserted with the correct polarity.
► Replacement of batteries must be done by an adult.

USER MANUAL

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and releases radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment and receiver to different electrical outlets.
—Consult the dealer or an experienced radio/TV technician for help.



1. PUSH TO OPEN BELT CLIP
2. REMOVE BATTERY DOOR
INSTALL 9V BATTERY

FCC ID: 2AE6BUSA20022
This device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received,
including interference that may cause undesired operation.

