



Battery - Front View




Battery - Rear View




Mainboard with Shielding - Front View



Mainboard without Shielding - Front View



Mainboard – Rear View




LCD – Front View




LCD – Rear View



GSM/PCS/UMTS-FDD Antenna View




WIFI/BT/BLE - Antenna View



LTE - Antenna View




Annex B.iii. Photograph: Test Setup Photo



Annex C. TEST SETUP AND SUPPORTING EQUIPMENT

Annex C.ii. TEST SET UP BLOCK

Block Configuration Diagram for Radiated Emissions



Annex C. ii. SUPPORTING EQUIPMENT DESCRIPTION

The following is a description of supporting equipment and details of cables used with the EUT.

Supporting Equipment:

Manufacturer	Equipment Description	Model	Serial No
AOC	Adapter	SC/10WA050200US	C023542

Supporting Cable:

Cable type	Shield Type	Ferrite Core	Length	Serial No
USB Cable	Un-shielding	No	0.8m	C023542

Annex C.ii. EUT OPERATING CONDITIONS

N/A

Annex D. User Manual / Block Diagram / Schematics / Partlist

N/A

Annex E. DECLARATION OF SIMILARITY

N/A