

# Hang-A-Round

## HANGING SPEAKER & SPEAKERPHONE



**1. Charging Port:** Use the provided mini-USB cord to charge the speaker.

**2. Phone:** Press to answer/hang-up a phone call. Press to "Pause" music when in Bluetooth mode.

**3. ON/OFF:** Turn the device ON & OFF.

**4. Indicator Light:** Shines BLUE when a device is paired. Shines RED while charging. Blinks RED when battery is low.

**5. AUX Input:** Plug in AUX cord to play songs from MP3 player, CD player & other external devices.

### Charging the Bluetooth® Speaker:

Plug the mini-USB cord into the side of the speaker. Then plug the USB into your computer's USB port. When charging, the red LED light will be on. Charge for 2-3 hours for 3-4 hrs of playing time. Unplug the USB cord once the speaker is fully charged. When the power gets low, the red light will blink and you will hear a beeping sound.

### Pairing the Bluetooth® Speaker:

1. Turn 'ON' the speaker by using the switch on the back. The blue lights will quickly blink until the speaker is connected.
2. In your device settings, turn the Bluetooth® function 'ON'. Make sure your device is no further than 3 feet away.
3. Wait for your device to recognize the speaker (Hang A Round Speaker).
4. Connect your device with the speaker (Hang A Round Speaker) by selecting that specific option in your device settings. The blue light will stay on once it is connected.

### Using the AUX Cable:

Connect the provided AUX cable to the speaker port and your external devices AUX port. Connecting a device using the AUX port will override Bluetooth® mode.

### To Use the Phone Function:

1. To answer a phone call, press the button on the side of the speaker.
2. To hang up a phone call, press the button. Press & hold press the button to decline any incoming calls.

***Do not use this speaker near water or in dusty conditions; damage may occur.***

### **Federal Communications Commission (FCC) Statement**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Warning:** Changes or modifications made to this device not expressly approved by **PAYA GROUP LIMITED** may void the FCC authorization to operate this device.

**Note:** The manufacturer is not responsible for any radio or tv interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.