

REALOV

T001

迷你智能震动棒 (Smartphone Controlled Vibrator)

Welcome to use REALOV™ T001.

T001 can be used as a conventional vibrator, as well as be connected to a smartphone through an APP, therefore providing you and your lover with a sensational and unexpected experience.

For more functions, please download the APP and refer to the “User’s Guide”, or visit www.realov.com

The product package includes,

1) T001 Vibrator

2) USB Cord

3) Storage Bag

4) User’s Guide

To Charge:

Insert one end of the data wire into the T001 and connect the other end to the USB port or USB/AC adapter (not included).

A red light indicates the T001 is charging .

When the T001 has fully charged the light will turn to green.

To Turn On and Off

To Turn On: Hold the button for 3 seconds until you feel it vibrate once. .

To Turn Off : Hold the button for 3 seconds until you feel it vibrate three times .

How To Use:

Manual mode (No Need for Smartphones)

After it is turned on, press the button briefly to shift through the 10 vibration modes.

Smartphone Control Mode:

Download and Install the App:

1) IOS System: Through the APP store, search “REALOV” to download and install.

Android System: Through Google Play, search “REALOV” for downloads and installations.

2) Scan the QR code on the packaging and follow the directions .

3) Download the APP at : www.realov.com

Initial Pairing

After T001 has been turned on, enable Bluetooth on the smartphone, the APP and the smartphone will automatically search T001 and finish the pairing process, then “Connected” will be displayed on the left upper corner of the smartphone screen.

Caution:

1. First time pairing in the Setting is a must for part of the Android smartphone. (Methods: Smartphone-Settings - Bluetooth - Scan - Pairing), then run the APP . (However in any case, please try to run the APP directly first)

2. When the T001 or the cell phone is low in power, the pairing will be affected. Please recharge it immediately.

Pairing cancellation:

Click the “Connected” button on the left upper corner of the screen to disconnect .

Successive Pairing (shaking for connection):

As long as the APP is not cancelled, shaking the cell phone can automatically begin the process.

For more function, please refer to the “User’s Guide” in the APP, or log on to : www.realov.com

Product parameters:

Material	Human-safe silicone ABS	Dimension	16X3.6X3.4 (cm)
Water-proof	Completely water proof	Weight	55g
Color	Cherry red, enchanted purple and ocean blue	Re-charging time	T001-FC: 3h T001-HC: 1h
Battery	Lithium ion battery	Use time	Max. 4h
Motor speed	1100r/m		

Maintenance

During Use: It is recommended that the T001 be used with water based lubricant, Do not use with silicone or oil lubricant as it will damage the surface of the product.

Cleaning: After each use, please wash with warm water and scented soap, or a toy cleaner.

Warranty:

There is a one-year warranty from the date of purchase. However, in case of the following circumstances, the warranty is invalid:

1. The product was damaged due to the improper use or unauthorized alterations.
2. The product was damaged due to a natural disaster such as earthquake , flood etc.

Designed and developed by

REALOV IDEAL LLC, USA

Made in China

© Realov Ideal LLC 2013-2015 copyright reserved.

www.realov.com

Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio

frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by Shanghai Realov Electronic Technology Co., Ltd may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or tv interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.